SHARP PARTS GUIDE

MX-FNX2
AR-PN1A / AR-PN1B
AR-PN1C / AR-PN1D
MODEL MX-RBX1

このパーツガイドに掲載されている表示価格ランクは消費税抜きです。

CONTENTS

1 取り付けｷｯﾄ (Mounting Hardware)
2 外装ｶﾊﾞｰ (Exterial Covers,Panels etc.)
3 本体機械内部 1(Internal Components 1)
4 本体機械内部 2(Internal Components 2)
5 ﾊﾟﾝﾁｬ部 (Puncher Assembly)[AR-PN1]
6 ﾊﾟﾝﾁｬﾄｰﾀﾙ部 (Puncher Total Assembly)[AR-PN1]
7 ｽﾀｯｸﾓｰﾀｰ駆動部 (Stack Motor Driver Assembly)
8 駆動部 (Drive Assembly)
9 束線押えｶﾊﾞｰ部 (Bundle Support Cover Assembly)
10 処理部 (Dispose Assembly)
11 搬送部 (Paper Feeder Assembly)
12 折り部 1/3(Fold Assembly 1/3)
13 折り部 2/3(Fold Assembly 2/3)
14 折り部 3/3(Fold Assembly 3/3)
15 ｽﾃｲﾌﾟﾙ部 1/2(Staple Assembly 1/2)
16 ｽﾃｲﾌﾟﾙ部 2/2(Staple Assembly 2/2)
17 梱包 & 付属品 (Packing Material & Accessories)
18 梱包 & 付属品 (Packing Material & Accessories) [AR-PN1]
19 DC ｺﾝﾄﾛｰﾗｰ回路基板 (DC CONTROLLER PCB ASSEMBLY)
20 前ｶﾊﾞｰﾕﾆｯﾄ (FRONT COVER UNIT)[MX-RBX1]
21 搬送部 No1 (TRANSPORT SECTION No.1)[MX-RBX1]
22 搬送部 No2 (TRANSPORT SECTION No.2)[MX-RBX1]
23 搬送部 No3 (TRANSPORT SECTION No.3)[MX-RBX1]
24 排紙ﾄﾚｲ & ﾚｰﾙ部 (DELIVERY PAPER TRAY & RAIL SECTION) [MX-RBX1]
25 梱包 & 付属品 (PACKING MATERIAL & ACCESSORIES) [MX-RBX1]
■ 索引 (Index)

補修部品のランク付

市場における補修部品の在庫管理が、適正に運営出来る手助けとなることを、目的とします。

Aランク ： メンテナンスパーツ、メンテナンスパーツには入っていないがメンテナンスパーツに近い消耗パーツ。
Bランク ： 性能・機能パーツ（センサー、クラッチ等の電気パーツ）、消耗パーツ。
Eランク ： 基板含むユニットパーツ。
Dランク ： 整備パーツ（外装、パッキング、同梱パーツ）。
Cランク ： 上記ランク以外のパーツ（基板の子部品を除いたもの）。

DEFINITION

Rank A : Maintenance parts, and consumable parts which are not included in but closely related to maintenance parts
Rank B : Performance/function parts (sensors, clutches, and other electrical parts), consumable parts
Rank E : Unit parts including PWB
Rank D : Preparation parts (External fitting, packing, parts packed together)
Rank C : Parts other than the above (excluding sub components of PWB)

安全性・信頼性確保のため部品は、必ず正規のものをご使用下さい。
⚠ 印の商品は、安全上重要な部品です。交換をする時は、安全及び性能維持のため必ず指定の部品をご使用下さい。

Because parts marked with "⚠" is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

○ 当モデルのサービス資料には、この資料以外にサービスマニュアル（回路図含む）があります。合わせてご利用下さい。
○ Other than this Parts Guide, please refer to documents Service Manual(including Circuit Diagram)of this model.
○ Please use the 13 digit code described in the right hand corner of front cover of the document, when you place an order.
○ For U.S. only-Use order codes provided in advertising literature. Do not order from parts department.

---

1 取り付けｷｯﾄ (Mounting Hardware)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4A18928000	BD	GN		C	BASE	ﾍﾞｰｽ
4	0CW4144P004//	BA	FX	N	C	STAND FOOT	ｽﾀﾝﾄﾞ足
6	0CW4A18919000	AN	EG		C	CASTER BRACKET	ｷｬｽﾀｰﾌﾞﾗｹｯﾄ
9	0CW4B10389000	AU	EZ		C	STAY	ｽﾃｰ
10	0CW4144K100//	BK	HC	N	C	FRAME	ﾌﾚｰﾑ
11	0CW4A18920000	AH	DX		C	BRACKET PIN	ﾌﾞﾗｹｯﾄﾋﾟﾝ
14	0CW4144P253//	BC	GD	N	D	FOOT COVER	足ｶﾊﾞｰ
20	0CW4B10391000	AD	DJ		C	AJUST SCREW	調整ﾈｼﾞ
24	0CW4144P251//	BC	GJ	N	D	COVER	ｶﾊﾞｰ
25	0CW4A18921000	AH	DX		C	CASTER	ｷｬｽﾀｰ
26	0CW4A18926000	AK	EB		C	BRACKET FRONT	ﾌﾞﾗｹｯﾄ前
27	0CW4A18927000	AK	EB		C	BRACKET REAR	ﾌﾞﾗｹｯﾄ後
29	0CWFS26593000	AD	DJ		C	GUIDE ROLLER	ｶﾞｲﾄﾞｺﾛ
30	0CW4A18934000	AR	EQ		C	PLATE RAIL GUIDE	ﾚｰﾙｶﾞｲﾄﾞ
31	0CW4A18936000	AX	FG		C	PLATE GUIDE RAIL	ｶﾞｲﾄﾞﾚｰﾙ
32	0CW4A18938000	AH	DX		C	SHAFT ROLLER	ｺﾛ軸
33	0CW4A18937000	AN	EQ		C	PLATE ROLLER	ｺﾛ支板
34	0CW4A18910000	AH	DX		C	EARTH SPRING	ｱｰｽ板ﾊﾞﾈ
35	0CW4A18939000	AF	DS		C	ROLLER	ｺﾛ
36	0CWFC30661000	AC	DJ		C	CLIP	ｸﾘｯﾌﾟ
37	0CW4A18923000	AM	EG		C	BRACKET	ﾌﾞﾗｹｯﾄ
38	0CW4144P005//	AU	FG	N	C	BRACKET	ﾌﾞﾗｹｯﾄ
39	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
41	0CWFC30779000	AC	DJ		C	SCREW(M3×6)	ﾋﾞｽ
43	0CW4A18935000	AF	DS		C	SHAFT ROLLER	ｺﾛ軸
44	0CW4A12609000	AC	DJ		C	SCREW(M4×18)	ﾋﾞｽ
46	0CW4144P250//	BD	GN	N	D	FRONT LOWER COVER	前下ｶﾊﾞｰ
47	0CW4144P254//	BF	GN	N	D	REAR LOWER COVER	後下ｶﾊﾞｰ
51	0CW4134P042//	AN	EQ		D	EARTH PLATE SPRING	ｱｰｽ板ｽﾌﾟﾘﾝｸﾞ
52	0CW4144P002//	AP	EQ	N	C	FRAME COVER	ﾌﾚｰﾑｶﾊﾞｰ
53	0CW4144P003//	AL	EB	N	C	COVER BRACKET	中央ｶﾊﾞｰﾌﾞﾗｹｯﾄ
54	0CWHW080FWS//	AC	DJ	N	C	WASHER(HW-80)	ﾜｯｼｬｰ
55	0CWCLP00010//	AD	DJ	N	C	E-RING	Eﾘﾝｸﾞ
56	0CW4144P252//	AM	EG	N	C	LOWER COVER	下ｶﾊﾞｰ
57	0CW040120FNBB	AB	DJ		C	TAPPING SCREW	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
58	0CW040100FNBi	AA	DD		C	SCREW	ﾋﾞｽ
601	0CW040080FZWS	AA	DD		C	SCREW(M3×8)	ﾋﾞｽ

1 取り付けｷｯﾄ (Mounting Hardware)



2 外装ｶﾊﾞｰ (Exteriors Covers,Panels etc.)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4A18857000	AG	DX		C	JAM CLEANING KNOB	JAM 処理ﾉﾌﾞ
2	0CW4144P202//	BK	HG	N	D	REAR COVER	後ｶﾊﾞｰ
3	0CW4144P726//	AY	FQ	N	D	FRAME JAM COVER	ﾌﾚｰﾑ JAM ｶﾊﾞｰ
4	0CW4144P210//	AL	EB	N	D	LATCH HANDLE	ﾗｯﾁﾊﾝﾄﾞﾙ
5	0CW4144K502//	BA	FX	N	C	INTERFACE HARNESS	ｲﾝﾀｰﾌｪｲｽﾊｰﾈｽ
6	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
7	0CW4144P206//	BA	FX	N	D	DUMMY PUNCHER COVER	ﾀﾞﾐｰﾊﾟﾝﾁｬｶﾊﾞｰ
9	0CW4144P763//	AT	EZ	N	C	DUMMY PUNCH GUIDE UPPER	ﾀﾞﾐｰﾊﾟﾝﾁｶﾞｲﾄﾞ上
10	0CW4144P391//	BA	FX	N	C	DUMMY PUNCH GUIDE	ﾀﾞﾐｰﾊﾟﾝﾁｶﾞｲﾄﾞ
11	0CW4144P235//	BA	FX	N	D	SIDE COVER	横ｶﾊﾞｰ
12	0CW4A17291000	AE	DS		C	TRAY UP/DOWN EMPTY LEVER	ﾄﾚｲ昇降ｴﾝﾌﾟﾃｨﾚﾊﾞｰ
13	0CW4B10780000	AF	DS		C	PAPER SENSING FLAG REAR	紙検知ﾌﾗｸﾞ後
14	0CW4A17415000	AG	DS		C	TENSION SPRING	引張ﾊﾞﾈ
15	0CW4A17378000	AD	DJ		C	UPPER COVER LATCH	上ｶﾊﾞｰﾗｯﾁ
16	0CW4144P205//	AK	EB	N	D	UPPER COVER HANDLE	上ｶﾊﾞｰ取手
17	0CW4144P203//	BB	GD	N	D	UPPER COVER	上ｶﾊﾞｰ
18	0CW4S12048000	AL	EB		C	TENSION SPRING F	ﾈｼﾞﾘﾊﾞﾈ F
19	0CW4S12049000	AL	EB		C	TENSION SPRING R	ﾈｼﾞﾘﾊﾞﾈ R
20	0CW4A17195000	AF	DS		C	ROLLER HOLDER	ｺﾛﾎﾙﾀﾞｰ
21	0CW4A17317000	AC	DJ		C	PAPER FEED ROLLER	搬送ｺﾛ
22	0CW4144P200//	BF	GN	N	D	FRONT COVER	前ｶﾊﾞｰ
23	0CW4144P201//	BE	GN	N	D	FRONT OPEN COVER	前ｵｰﾌﾟﾝｶﾊﾞｰ
24	0CW4A18313000	AE	DJ		C	COVER BAND	ｶﾊﾞｰｽﾄﾗｯﾌﾟ
25	0CW4B10585000	AD	DJ		C	SUPPORT PANEL BAND 2	ｶﾊﾞｰｽﾄﾗｯﾌﾟｻﾎﾟｰﾄ2
26	0CW4144P727//	BE	GN	N	C	STACK TRAY 1	ｽﾀｯｸﾄﾚｲ 1
27	0CW4144P728//	BA	FX	N	C	STACK TRAY 2	ｽﾀｯｸﾄﾚｲ 2
28	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
29	0CW4A17424000	AF	DS		C	EARTH PLATE	ｱｰｽ板
30	0CW4144P393//	AS	EQ	N	D	DOME PLATE 1	ﾄﾞｰﾑ板 1
31	0CW4144P394//	AX	FG	N	D	DOME PLATE 2	ﾄﾞｰﾑ板 2
32	0CW4A17270000	AG	DS		C	BASE TRAY FLAG	ﾍﾞｰｽﾄﾚｲﾌﾗｸﾞ
33	0CW4144P213//	BC	GJ	N	C	SADDLE TRAY	ｻﾄﾞﾙﾄﾚｲ
34	0CW4144P381//	AK	EB	N	C	STOPPER ARM	ｽﾄｯﾊﾟｱｰﾑ
35	0CW4A17400000	AC	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
36	0CW4A17408000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
39	0CW4A18338010	AH	DX		C	DUMMY PUNCHER PAPER GUIDE	ﾀﾞﾐｰﾊﾟﾝﾁ紙ｶﾞｲﾄﾞ
40	0CW4144P433//	AY	FQ	N	D	STAPLE REMOVING LABEL	JAM 処理ﾗﾍﾞﾙ
41	0CW4A17284000	AD	DJ		C	GEAR(48T/15T)	ｷﾞｱ
43	0CW4B10584000	AD	DJ		C	SUPPORT PANEL BAND 1	ｶﾊﾞｰｽﾄﾗｯﾌﾟｻﾎﾟｰﾄ1
50	0CW4B10851000	AD	DX		C	TRAY RIB SMALL	ﾄﾚｲﾘﾌﾞ小
51	0CW4B10845000	AD	DJ		C	SPONGE	ｽﾎﾟﾝｼﾞ
52	0CW4B10395000	AL	EB		C	TRAY BRACKET F	ﾄﾚｲﾌﾞﾗｹｯﾄ F
53	0CW4B10394000	AL	EB		C	TRAY BRACKET R	ﾄﾚｲﾌﾞﾗｹｯﾄ R
56	0CW4144P217//	AE	DS	N	C	FRONT COVER BAND	前ｶﾊﾞｰｽﾄﾗｯﾌﾟ
57	0CW4144K501//	BC	GJ	N	C	CONNECTION HARNESS	中継ﾕﾆｯﾄ接続ﾊｰﾈｽ
58	0CW4A17380000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
61	0CW4144P204//	BC	GD	N	D	UPPER COVER GUIDE	上ｶﾊﾞｰｶﾞｲﾄﾞ
62	0CW4144P207//	AR	EQ	N	C	DUCT PUNCH	ﾊﾟﾝﾁﾀﾞｸﾄ
63	0CW4144P208//	AN	EQ	N	D	FRONT UPPER COVER	前上ｶﾊﾞｰ
64	0CW4144P211//	AH	DX	N	C	LATCH HOLDER	ﾗｯﾁﾎﾙﾀﾞｰ
65	0CW4144P209//	AP	EQ	N	D	REAR UPPER COVER	後上ｶﾊﾞｰ
66	0CWER060SKN//	AA	DJ	N	C	E-RING(ER-060)	Eﾘﾝｸﾞ
67	0CW4144P216//	AF	DS	N	C	FUNCTIONAL LEVER	機能部ﾚﾊﾞｰ
68	0CW4144P401//	AH	DX	N	C	FUNCTIONAL SPRING	機能部ｽﾌﾟﾘﾝｸﾞ
69	0CW4144P100//	AZ	FQ	N	C	FUNCTIONAL SHAFT	機能部ｼｬﾌﾄ
70	0CW4144P007//	AG	DX	N	C	FUNCTIONAL BRACKET	機能部ﾌﾞﾗｹｯﾄ
71	0CW4099Q031//	AD	DJ	N	C	WASHER	ｼｬﾌﾄ固定ﾜｯｼｬｰ
72	0CW040100FWWS	AC	DJ	N	C	SCREW	ｼｬﾌﾄ固定ﾋﾞｽ
73	0CW4144P214//	AP	EQ	N	D	MAINTENANCE COVER	ﾒﾝﾃﾅﾝｽｶﾊﾞｰ
74	0CW0412FNBiT2	AC	DJ	N	C	SCREW	ﾋﾞｽ
75	0CW3090P360//	AD	DJ		C	WASHER	ﾜｯｼｬｰ
76	0CW4144P220//	AH	DX	N	D	FRONT JAM SUB COVER	前 JAM ｻﾌﾞｶﾊﾞｰ
77	0CW4144P222//	AH	DX	N	D	REAR JAM SUB COVER	後 JAM ｻﾌﾞｶﾊﾞｰ
78	0CW4113P027A/	AK	DX		C	ROLLER PLATE SPRING	ｺﾛ板ﾊﾞﾈ
79	0CW040120FNBB	AB	DJ		C	TAPPING SCREW	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
80	0CW040060FNBi	AA	DD		C	SCREW	ﾋﾞｽ
81	0CWXB47401006	AB	DJ		C	SCREW TAPPING	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
82	0CW4048P076//	AD	DJ	N	C	SCREW	ﾋﾞｽ
83	0CW4144P950//	AC	DJ	N	C	SPEED NUT	ｽﾋﾟｰﾄﾞﾅｯﾄ
84	0CW4144P469//	BC	GJ	N	B	DISCHARGE BRUSH	除電ﾌﾞﾗｼ
85	0CW4144P402//	AE	DS	N	C	LATCH HANDLE SPRING	ﾗｯﾁﾊﾝﾄﾞﾙｽﾌﾟﾘﾝｸﾞ
86	0CW4110P026//	AM	EG	N	C	TRAY STAY	ﾄﾚｲｽﾃｲ
502	0CWXB47401007	AB	DJ		C	SCREW TAPPING(M4×10)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
503	0CWXB47300607	AB	DJ		C	SCREW TAPPING(M3×6)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
504	0CW4B10848000	AB	DJ		C	SCREW(M4×6)	ﾋﾞｽ

2 外装ｶﾊﾞｰ (Exteriors Covers,Panels etc.)



3 本体機械内部 1 (Internal Components 1)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4109P247//	AY	FQ	N	C	GEAR(24T)	ｷﾞｱ
2	0CW4A17577000	AE	DS		C	STACK LEVER	ｽﾀｯｸﾚﾊﾞｰ
3	0CW4A17259000	AD	DJ		C	GEAR(16T/18T)	ｷﾞｱ
4	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
5	0CWFS19009000	AC	DJ		C	SCREW STEPPED(M3)	ﾀﾞﾝﾋﾞｽ
6	0CW4A17353010	AE	DJ		C	BELT HOLDER REAR	ﾍﾞﾙﾄﾎﾙﾀﾞｰ後
7	0CW4A17354000	AE	DJ		C	BELT HOLDER FRONT	ﾍﾞﾙﾄﾎﾙﾀﾞｰ前
8	0CW4A17371000	AC	DJ		C	TENSIONER ROLLER	ﾃﾝｼｮﾅｺﾛ
9	0CW4144P400//	AD	DJ	N	C	LATCH SPRING	ﾗｯﾁﾊﾞﾈ
10	0CW4A17414000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
11	0CW4A17417000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
12	0CW4A17419000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
13	0CW4109P248//	AV	FG	N	C	GEAR(18T/24T)	ｷﾞｱ
14	0CW4A17517000	AE	DS		C	LATCH	ﾗｯﾁ
15	0CW4144P212//	AG	DX	N	C	LATCH ARM	ﾗｯﾁｱｰﾑ
16	0CW4H16512000	AF	DS		C	CABLE STACK SENSOR	ｽﾀｯｸｾﾝｻｰ束線
17	0CW4A17523000	AC	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
18	0CW4A17524000	AD	DJ		C	PULLEY(18T)	ﾌﾟｰﾘｰ
19	0CW4A17528000	AC	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
20	0CW4A17542000	AC	DJ		C	FLANGE	ﾌﾗﾝｼﾞ
21	0CW4A17567000	AD	DJ		C	CLIP SHAFT	軸ｸﾘｯﾌﾟ
22	0CW4A17572000	AE	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
23	0CW4A17691000	AC	DJ		C	LEAF SPRING	板ﾊﾞﾈ
24	0CW4A17288000	AD	DJ		C	PULLEY(40T)	ﾌﾟｰﾘｰ
25	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
26	0CW4S19077000	AC	DJ		C	SCREW(M4×8)	ﾋﾞｽ
27	0CW4F11556000	AG	DX		C	PLATE PAPER FEED TENSIONER	搬送ﾃﾝｼｮﾅ板
28	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
29	0CW4A17265000	AC	DJ		C	RAIL ROLLER	ﾚｰﾙｺﾛ
31	0CW4A17318000	AK	DX		C	STOPPER GUIDE	処理ｽﾄｯﾊﾟｶﾞｲﾄﾞ
32	0CW4A17539000	AK	DX		C	LINK 1	ﾘﾝｸ 1
33	0CW4A17540000	AC	DJ		C	LINK 2	ﾘﾝｸ 2
34	0CW4A17549000	AC	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
35	0CW4K11080000	BF	GN		B	STEPPING MOTOR	ｽﾃｯﾋﾟﾝｸﾞﾓｰﾀｰ
36	0CWFC25034000	AB	DJ		C	SCREW W/WASHER(M3×6)	ﾊﾞﾈ付ﾅﾍﾞﾋﾞｽ
37	0CW4A17355000	AD	DJ		C	PULLEY(18T)	ﾌﾟｰﾘｰ
38	0CWXF21817960	AS	EZ		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
39	0CWXF21619860	AQ	EQ		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
40	0CWXF21618840	AP	EQ		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
41	0CW4H16460000	AP	EQ		C	CABLE SENSOR	ｾﾝｻｰ束線
42	0CW4H16602000	AU	EZ		C	BUNDLE WIRE FOR THE PADDLE MOTOR	ﾊﾞﾝﾄﾞﾙﾜｲﾔｰ
43	0CW4H16467000	AP	EQ		C	CABLE DC MOTOR	DC ﾓｰﾀｰ束線
44	0CW4A17321000	AR	EQ		C	STOPPER ARM	ｽﾄｯﾊﾟｱｰﾑ
45	0CW4A17400000	AC	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
46	0CWXF21605040	AL	EB		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
47	0CW4F11882000	AT	EZ		C	TRAY STAY F	ﾄﾚｲｽﾃｲ F
48	0CW4144P016//	AG	DX	N	C	LATCH GUIDE PIN	ﾗｯﾁﾋﾟﾝｶﾞｲﾄﾞ
49	0CW4A17578000	AD	DJ		C	PAD	ﾊﾟｯﾄﾞ
50	0CW4B10785000	AC	DJ		C	PAD	ﾊﾟｯﾄﾞ
51	0CW4B10390000	AN	EQ		C	MOTOR PLATE	ﾓｰﾀｰﾌﾟﾚｰﾄ
52	0CW4F11883000	AN	EQ		C	TRAY STAY R	ﾄﾚｲｽﾃｲ R
53	0CW4A17576000	AH	DX		C	STACK LEVER BRACKET	ｽﾀｯｸﾚﾊﾞｰﾌﾞﾗｹｯﾄ
54	0CW4A17482000	AP	EQ		C	FR-ST STAY	FR-ST ｽﾃｲ
55	0CW4A17491000	AW	FG		C	STAY FRAME	ｽﾃｲﾌﾚｰﾑ
56	0CW4A17511000	AR	EQ		C	FR DUCT RU	FR ﾀﾞｸﾄ RU
57	0CW4A17217000	AV	FG		C	STACK SHAFT	ｽﾀｯｸ軸
58	0CW4A17510000	AK	DX		C	CABLE GUIDE(MIDDLE REAR)	束線ｶﾞｲﾄﾞ (中後)
59	0CW4A17253000	AS	EZ		C	FRAME LATCH SHAFT	ﾌﾚｰﾑﾗｯﾁ軸
60	0CW4F11560000	AH	DX		C	PULLEY SUPPORT PLATE(FRONT LOWER)	ﾌﾟｰﾘｰ支板 (前下)
61	0CW4A17512000	AE	DJ		C	CABLE GUIDE(REAR LOWER)	束線ｶﾞｲﾄﾞ (後下)
62	0CW4A17543000	AE	DS		C	CABLE GUIDE	束線ｶﾞｲﾄﾞ
63	0CW4A17489000	AG	DS		C	STACK MOTOR REINFORCEMENT PLATE	ｽﾀｯｸﾓｰﾀｰ補強板
64	0CW4A17474000	AG	DS		C	RISE AND FALL SUPPORT PLATE(FRONT)	昇降押え板 (前)
65	0CW4F11558000	AH	DX		C	PULLEY SUPPORT PLATE(REAR LOWER)	ﾌﾟｰﾘｰ支板 (後下)
66	0CW4A17475000	AH	DX		C	TS SUPPORT PLATE(REAR)	TS 押え板 (後)
67	0CW4109P427//	AC	DJ	N	C	SCREW(M4×7)	ﾋﾞｽ
68	0CW4109P207//	AD	DJ	N	C	SPACER COLLAR	ｽﾍﾟｰｻｰｶﾗｰ
501	0CWXD32200142	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
502	0CWXB47401007	AB	DJ		C	SCREW TAPPING(M4×10)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
503	0CWXD12300142	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

3 本体機械内部 1 (Internal Components 1)



FCP08973

4 本体機械内部 2 (Internal Components 2)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4144P705//	AL	EB	N	D	INTERFACE HOLDER	ｲﾝﾀｰﾌｪｲｽﾎﾙﾀﾞｰ
2	0CW4S19077000	AC	DJ		C	SCREW(M4×8)	ﾋﾞｽ
3	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
4	0CW4B10586010	AC	DJ		C	PLATE STAPLER FRAME STOPPER	ｽﾃｲﾌﾟﾗﾌﾚｰﾑ ｽﾄｯﾊﾟ
5	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
6	0CWFS21672000	AD	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
7	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
8	0CW4A18316000	AD	DJ		D	BLANKING COVER	目隠しｶﾊﾞｰ
9	0CW4A17515000	AC	DJ		C	FRAME TRAY ROLLER	処理ﾄﾚｲｺﾛ
10	0CW4A17172010	AN	EQ		C	PAPER GUIDE LOWER	通紙ｶﾞｲﾄﾞ下
11	0CW4A17349000	AF	DS		C	SENSOR FLAG	ｾﾝｻｰﾌﾗｸﾞ
12	0CW4A17418000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
13	0CW4H16454000	AE	DS		C	CABLE SENSOR	ｾﾝｻｰ束線
14	0CW4A17371000	AC	DJ		C	TENSIONER ROLLER	ﾃﾝｼｮﾅｺﾛ
15	0CW4F11557000	AH	DX		C	PLATE PAPER FEED TENSIONER 2	搬送ﾃﾝｼｮﾅ板 2
16	0CW4060P027//	AB	DJ	N	C	SCREW	ﾋﾞｽ
17	0CW4H16449010	AM	EG		B	MICROSWITCH	ﾏｲｸﾛｽｲｯﾁ
18	0CWXF21607440	AK	DX		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
19	0CW4A17505000	AD	DJ		C	TOP SENSOR FLAG	ﾄｯﾌﾟｾﾝｻｰﾌﾗｸﾞ
20	0CW4A17506000	AE	DS		C	SWITCH LEVER	ｽｲｯﾁﾚﾊﾞｰ
21	0CW4A17507000	AD	DJ		C	LEVER SUPPORT HOLDER	ﾚﾊﾞｰ押えﾎﾙﾀﾞｰ
22	0CW4A17508000	AG	DX		C	SENSOR/MICROSWITCH HOLDER	ｾﾝｻｰ/ﾏｲｸﾛｽｲｯﾁﾎﾙﾀﾞｰ
23	0CW4144P314//	AD	DJ	N	C	ROLLER GEAR(24T)	ﾛｰﾗｰｷﾞｱ
24	0CW4144P215//	AL	EB	N	C	PAPER WEIGHT GUIDE 1	重りｶﾞｲﾄﾞ 1
25	0CW4A17495000	AD	DJ		C	WEIGHT PLATE 1	重り板 1
26	0CW4A17496000	AD	DJ		C	WEIGHT PLATE 2	重り板 2
27	0CW4144P751//	AG	DX	N	C	PAPER WEIGHT GUIDE 2	重りｶﾞｲﾄﾞ 2
28	0CW4A17488000	AV	FG		D	FRAME COVER	ﾌﾚｰﾑｶﾊﾞｰ
29	0CW4A18314000	AC	DJ		C	LEAF EARTH COVER	ｱｰｽ板ﾊﾞﾈ
30	0CW4H16452000	AQ	EQ		C	FRONT DOOR SENSOR CABLE	前ﾄﾞｱｾﾝｻｰ束線
31	0CW4H16453000	AU	EZ		C	LEVER TRAY SENSOR CABLE	ﾚﾊﾞｰﾄﾚｲｾﾝｻｰ束線
32	0CW4H16461000	AN	EQ		C	SENSOR CABLE 2	ｾﾝｻｰ束線 2
33	0CW4H16462000	AL	EB		C	SENSOR CABLE 3	ｾﾝｻｰ束線 3
34	0CW4A17409000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
35	0CW4H16465000	AQ	EQ		C	JOG MOTOR CABLE	ｼﾞｮｸﾞﾓｰﾀｰ束線
36	0CW4H16553000	AS	EQ		C	SWITCH CABLE	ｽｲｯﾁ束線
37	0CW4134K328//	AF	DS		C	BIND CLUTCH CABLE	ﾊﾞｲﾝﾄﾞｸﾗｯﾁ束線
38	0CW4116P405B/	BA	FX		C	PAPER FEED ROLLER	搬送ﾛｰﾗｰ
39	0CW4048P300//	AC	DJ		C	SCREW	ﾋﾞｽ
40	0CW4A17467000	AF	DS		C	SENSOR BRACKET	ｾﾝｻｰﾌﾞﾗｹｯﾄ
41	0CW4A18951000	AG	DX		C	JOINT-SWITCH HOLDER	ｼﾞｮｲﾝﾄｽｲｯﾁﾎﾙﾀﾞｰ
42	0CW4A18948000	AN	EG		C	GROUNDING PLATE	ｸﾞﾗｳﾝﾃﾞｨﾝｸﾞﾌﾟﾚｰﾄ
43	0CW4A18869000	AE	DS		C	SWITCH LEVER	ｽｲｯﾁﾚﾊﾞｰ
44	0CW4A18863000	AE	DJ		C	SPRING	ｽﾌﾟﾘﾝｸﾞ
46	0CW4144K302//	CE	UF	N	E	DC CONTROLLER PWB ASSEMBLY	DC ｺﾝﾄﾛｰﾗｰ回路基板
47	0CW4A17426000	AH	DX		C	PROCESSING TRAY FRAME LOCK PLATE 2	処理ﾄﾚｲﾌﾚｰﾑﾛｯｸ板 2
48	0CW4A17425000	AE	DS		C	PROCESSING TRAY FRAME LOCK PLATE 1	処理ﾄﾚｲﾌﾚｰﾑﾛｯｸ板 1
49	0CWVT25019030	AE	DS		C	SLIP GUIDE	ｽﾘｯﾌﾟｶﾞｲﾄﾞ
50	0CWVT20002018	AE	DJ		C	PWB SPACER	基板ｽﾍﾟｰｻｰ
51	0CWVT25171030	AE	DS		C	PWB SPACER	基板ｽﾍﾟｰｻｰ
501	0CWXB47401007	AB	DJ		C	SCREW TAPPING(M4×10)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
502	0CWXD32200122	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

4 本体機械内部 2 (Internal Components 2)



5 ﾊﾟﾝﾁｬ部 (Puncher Assembly)[AR-PN1]

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4G11297020	CA	TR		E	PUNCHER CONTROLLER PWB ASSEMBLY	ﾊﾟﾝﾁｬｺﾝﾄﾛｰﾗｰ回路基板
2	0CW4A18685000	AF	DS		C	PUNCHER SHUTTER	ﾊﾟﾝﾁｬｼｬｯﾀｰ
3	0CW4H16514000	AP	EQ		C	CABLE POWER CONNECTING	電源中継束線
4	0CW4H16515000	AH	DX		C	CABLE INTERFACE	ｲﾝﾀｰﾌｪｲｽ束線
5	0CW4A18683000	AE	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
6	0CW4H16524000	AV	FG		C	CABLE SENSOR	ｾﾝｻｰ束線
7	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
8	0CW4B10489000	AF	DS		D	LABEL	ﾊﾟﾝﾁｸｽﾞｽﾃﾗﾍﾞﾙ
9	0CW4A18672000	AY	FQ		C	PUNCHER MOUNT	ﾊﾟﾝﾁｬ台
10	0CW4A18673000	AF	DS		D	HARNESS COVER	ﾊｰﾈｽｶﾊﾞｰ
11	0CW1020K367//	AP	EQ	N	E	DUST LED PWB UNIT	ﾀﾞｽﾄ LED 回路基板
12	0CW1020K369//	AP	EQ	N	E	DUST PTR PWB UNIT	ﾀﾞｽﾄ PTR 回路基板
13	0CW4A18679000	AF	DS		C	GEAR(16T/33T)	ｷﾞｱ
14	0CW4A18680000	AF	DS		C	GEAR(19T/32T)	ｷﾞｱ
15	0CW4A18681000	AM	EG		C	PUNCHER DUCT	ﾊﾟﾝﾁｬﾀﾞｸﾄ
16	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
17	0CW4A18686000	AT	EZ		D	DUST BOX PANEL	ﾀﾞｽﾄﾎﾞｯｸｽ
18	0CW4B10495000	AQ	EQ		D	DUST BOX COVER	ﾀﾞｽﾄﾎﾞｯｸｽｶﾊﾞｰ
19	0CW4K11078000	BB	FX		B	STEPPING MOTOR	ｽﾃｯﾋﾟﾝｸﾞﾓｰﾀｰ
20	0CW4H16530000	AG	DX		C	CABLE DUST SENSOR	ｸｽﾞ検知束線
21	0CW4A18704000	AN	EQ		D	PUNCHER BASE COVER	ﾊﾟﾝﾁｬﾍﾞｰｽｶﾊﾞｰ
22	0CW4A18708000	AY	FQ		C	DUST BOX MYLAR	ﾀﾞｽﾄﾎﾞｯｸｽﾏｲﾗｰ
23	0CW4B10847000	AF	DS		D	DUST-BOX RUBBER	ﾀﾞｽﾄﾎﾞｯｸｽﾗﾊﾞｰ
25	0CW4B10493000	AE	DS		C	DUST BOX SPONGE	ﾀﾞｸﾄﾎﾞｯｸｽｽﾎﾟﾝｼﾞ
26	0CW4144K146//	AW	FG	N	E	PUNCHER GUIDE UNIT	ﾊﾟﾝﾁ入口ｶﾞｲﾄﾞﾕﾆｯﾄ
27	0CW4144P245//	AS	EZ	N	C	PUNCHER GUIDE	ﾊﾟﾝﾁ入口ｶﾞｲﾄﾞ
28	0CW4144P445//	AH	DX	N	C	PUNCHER GUIDE SHEET	ﾊﾟﾝﾁ入口ｶﾞｲﾄﾞﾏｲﾗｰ
29	0CW030080FDBB	AB	DJ	N	C	SCREW(3×8)	ﾋﾞｽ
50	0CW1020P537A/	BS	MJ		B	IC M38039FFSP CPU	CPU
51	0CWWA70484000	AN	EG		B	IC S-93C46ADP EP-ROM	EP-ROM
52	0CW4F11850000	AU	EZ		C	PC-PM-SUB BASE ASSY	PC-PM ｻﾌﾞﾍﾞｰｽ
53	0CW4B10494000	AS	EQ		C	DUST BOX SHEET	ﾀﾞｽﾄﾎﾞｯｸｽｼｰﾄ
54	0CW1020P280A/	AH	DX		C	RIB	ﾘﾌﾞ
55	0CW4A18684000	AF	DS		C	PC SENSOR PLATE	PC ｾﾝｻｰﾌﾟﾚｰﾄ
56	0CW4A18689000	AF	DS		C	PC-PWB FILM	PC 基板ﾌｨﾙﾑ
501	0CWXB12400605	AB	DJ		C	SCREW(M4×6)	ﾋﾞｽ
502	0CWXB47300805	AB	DJ		C	SCREW TAPPING(M3×8)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
503	0CWXD11104629	AC	DJ		C	WASHER	ﾜｯｼｬｰ
504	0CWXB24300605	AB	DJ		C	SCREW W/WASHER(M3×6)	ﾊﾞﾈ付ﾅﾍﾞﾋﾞｽ

5 ﾊﾟﾝﾁｬ部 (Puncher Assembly)[AR-PN1]



6 ﾊﾟﾝﾁｬﾄｰﾀﾙ部 (Puncher Total Assembly)[AR-PN1]

NO.	PARTS CODE	PRICE RANK Ex.	PRICE RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	
1	0CW4A18688000	AD	DJ		C	PUNCHER ROLLER	ﾊﾟﾝﾁｬｺﾛ
2	0CW4H16523000	BA	FX		C	CABLE REGISTRETION SENSOR	ﾚｼﾞｽﾄｾﾝｻｰ束線
3	0CWFS19102000	AC	DJ		C	SCREW STEPPED(M3)	ﾀﾞﾝﾋﾟｽ
4	0CWFS56528000	AE	DJ		C	EARTH ROLLER	ｱｰｽｺﾛ
5	0CW4A18682000	AG	DX		D	REGSTRETION COVER	ﾚｼﾞｽﾄｶﾊﾞｰ
6	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
7	0CWFF60507000	AV	FG		C	SENSOR HOLDER UPPER	ﾄｳｶｾﾝｻｰﾎﾙﾀﾞｰ上
8	0CWFF60508000	AV	FG		C	SENSOR HOLDER LOWER	ﾄｳｶｾﾝｻｰﾎﾙﾀﾞｰ下
9	0CWFB56775000	AH	DX		C	ENSOR FLAG PLATE	ｾﾝｻｰﾌﾗｸﾞ板
10	0CW4B10476000	AG	DS		D	JAM CLEARING COVER	JAM 処理ｶﾊﾞｰ
11	0CWFB55968000	AH	DX		C	SLIDE RACK	ｽﾗｲﾄﾞﾗｯｸ
12	0CW4B10477000	AG	DS		C	JAM CLEANING KNOB	JAM 処理ﾉﾌﾞ
14	0CW1033K300//	BD	GN	N	B	MOTOR DC	DC ﾓｰﾀｰ
15	0CW4H16531000	AP	EQ		C	CABLE MOTOR	ﾓｰﾀｰ束線
16	0CW1020K363B/	AX	FG		E	PWB UNIT	回路基板
17	0CW1020K365B/	AX	FG		E	PWB UNIT	回路基板
20	0CW4B10490000	AG	DX		C	SPRING	ｽﾌﾟﾘﾝｸﾞ
21	0CW4A18690000	AH	DX		C	PC SENSOR BRACKET	PC ｾﾝｻｰﾌﾞﾗｹｯﾄ
22	0CWFB55969000	AE	DJ		C	BEARING SLIDE	ﾍﾞｱﾘﾝｸﾞｽﾗｲﾄﾞ
501	0CWXB12300605	AB	DJ		C	SCREW(M3×6)	ﾋﾞｽ
502	0CWXB47300805	AB	DJ		C	SCREW TAPPING(M3×8)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
503	0CWXD21100502	AC	DJ		C	E-RING	E ﾘﾝｸﾞ
504	0CWXB47301209	AB	DJ		C	SCREW TAPPING(M3×12)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
505	0CWXB24300805	AB	DJ		C	SCREW W/WASHER(M3×8)	ﾊﾞﾈ付ﾅﾍﾞﾋﾞｽ
506	0CWXD21100642	AC	DJ		C	E-RING	E ﾘﾝｸﾞ
507	0CWXB12300805	AB	DJ		C	SCREW(M3×5)	ﾋﾞｽ
508	0CWXB12400805	AB	DJ		C	SCREW(M4×6)	ﾋﾞｽ

6 ﾊﾟﾝﾁｬﾄｰﾀﾙ部 (Puncher Total Assembly)[AR-PN1]



FCP08976

7 ｽﾀｯｸﾓｰﾀｰ駆動部 (Stack Motor Driver Assembly)

NO.	PARTS CODE	PRICE RANK Ex.	PRICE RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	
1	0CW4A17260000	AF	DS		C	GEAR(16T/40T)	ｷﾞｱ
2	0CW4A17261000	AG	DS		C	GEAR(16T/45T)	ｷﾞｱ
3	0CW4A17262000	AE	DS		C	GEAR(16T/45T)	ｷﾞｱ
4	0CW4A17263000	AE	DS		C	PULLEY(56T)	ﾌﾟｰﾘｰ
5	0CW4H16458000	AK	DX		C	CABLE SHIFT MOTOR	ｼﾌﾄﾓｰﾀｰ束線
6	0CW4135K550／／	BD	GN		B	MOTOR(NA3550D01C)	DC ﾓｰﾀｰ
7	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
8	0CWFC25034000	AB	DJ		C	SCREW W/WASHER(M3×6)	ﾊﾞﾈ付ﾅﾍﾞﾋﾞｽ
9	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
10	0CWFS21672000	AD	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
11	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
12	0CWXF21608040	AN	EG		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
13	0CW4A17264000	AE	DJ		C	CLOCK SENSOR PLATE	ｸﾛｯｸｾﾝｻｰ板
14	0CW4A17469000	AD	DJ		C	STACK MOTOR SUB PLATE	ｽﾀｯｸﾓｰﾀｰｻﾌﾞﾌﾟﾚｰﾄ
15	0CW4F11562000	AT	EZ		C	STACK MOTOR PLATE ASSY	ｽﾀｯｸﾓｰﾀｰﾌﾟﾚｰﾄ
16	0CW4A17173000	AD	DJ		C	CLOCK SENSOR BRACKET	ｸﾛｯｸｾﾝｻｰﾌﾞﾗｹｯﾄ
501	0CWXD32200122	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
502	0CWXD32200142	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

7 ｽﾀｯｸﾓｰﾀｰ駆動部 (Stack Motor Driver Assembly)



8 駆動部 (Drive Assembly)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4A17301000	AE	DS		C	GEAR(58T)	ｷﾞｱ
2	0CW4A17302000	AQ	EQ		C	GEAR(23T)	ｷﾞｱ
3	0CW4A17303000	AK	DX		C	GEAR(17T/65T)	ｷﾞｱ
4	0CW4A17304000	AL	EB		C	GEAR(15T/54T)	ｷﾞｱ
5	0CW4A17305000	AL	EB		C	GEAR(17T/29T)	ｷﾞｱ
6	0CW4A17306000	AH	DX		C	GEAR(20T)	ｷﾞｱ
7	0CW4A17307000	AF	DS		C	PULLEY(45T)	ﾌﾟｰﾘｰ
8	0CW4A17338000	AH	DX		C	GEAR(82T)	ｷﾞｱ
9	0CW4A17566000	AD	DJ		C	CLIP SHAFT	軸ｸﾘｯﾌﾟ
10	0CW4A17567000	AD	DJ		C	CLIP SHAFT	軸ｸﾘｯﾌﾟ
11	0CW4A17572000	AE	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
12	0CW4A17573000	AE	DS		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
13	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
14	0CWFS21615000	AS	EZ		C	BALL BEARING	ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ
15	0CWXF21807000	AP	EQ		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
16	0CW4A17300000	AD	DJ		C	GEAR(29T)	ｷﾞｱ
17	0CWFC25031000	AC	DJ		C	SCREW(M4×6)	ﾋﾞｽ
18	0CW4A17308000	AS	EZ		C	CLOCK SENSOR FLAG	ｸﾛｯｸｾﾝｻｰﾌﾗｸﾞ
19	0CW4K11069000	BR	LX		B	DC MOTOR(DC24V)	DC ﾓｰﾀｰ
20	0CWWG85421000	AR	EQ		B	PHOTO INTERRUPTER	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
21	0CW4A17407000	AD	DJ		C	COMPRESSION SPRING	圧縮ﾊﾞﾈ
22	0CW4H16468000	AY	FQ		C	CABLE STAPLER	ｽﾃｲﾌﾟﾗ束線
23	0CW4S19049000	AD	DJ		C	SCREW STEPPED	段ﾋﾞｽ
24	0CW4A17479000	AD	DJ		C	DRAWER D PLATE	ﾄﾞﾛﾜ D ﾌﾟﾚｰﾄ
25	0CW4A17516000	AK	DX		C	DRAWER D BRACKET	ﾄﾞﾛﾜ D ﾌﾞﾗｹｯﾄ
26	0CW4A17199000	AE	DJ		C	MOTOR SENSOR PLATE	ﾓｰﾀｰｾﾝｻｰﾌﾟﾚｰﾄ
27	0CW4F11563010	BA	FX		C	DRIVE GEAR BRACKET ASSY	駆動ｷﾞｱﾌﾞﾗｹｯﾄ
28	0CW4A17229000	AL	EB		C	GEAR SHAFT 1	ｷﾞｱｼｬﾌﾄ
29	0CW4A17231000	AL	EB		C	GEAR SHAFT 2	ｷﾞｱｼｬﾌﾄ
30	0CW4A17198000	AQ	EQ		C	DRIVE GEAR BRACKET ASSY	駆動ｷﾞｱﾌﾞﾗｹｯﾄ
501	0CWXD32200142	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
502	0CWXD32300182	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
503	0CWXD32200122	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

8 駆動部 (Drive Assembly)



9 束線押えｶﾊﾞｰ部 (Bundle Support Cover Assembly)

NO.	PARTS CODE	PRICE RANK Ex.	PRICE RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	
1	0CW4H16454000	AE	DS		C	CABLE SENSOR	ｾﾝｻｰ束線
2	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
3	0CW4A17416000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
5	0CW4A17371000	AC	DJ		C	TENSIONER ROLLER	ﾃﾝｼｮﾅｺﾛ
6	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
7	0CW4A17240000	AM	EG		C	SUPPORT SHAFT	押え軸
8	0CW4A17289000	AF	DS		C	GEAR(20T/28T)	ｷﾞｱ
9	0CW4113P243//	AE	DS		C	PAPER SENSOR LEVER	紙面検知ﾚﾊﾞｰ
10	0CW4A17325000	AE	DS		C	GEAR(5T)	ｷﾞｱ
11	0CW4A17367000	AD	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
12	0CW4A17421000	AE	DJ		C	TENSION SPRING	ﾈｼﾞﾘﾊﾞﾈ
13	0CW4A17422000	AE	DS		C	TENSION SPRING	ﾈｼﾞﾘﾊﾞﾈ
14	0CW4A17423000	AE	DS		C	TENSION SPRING	ﾈｼﾞﾘﾊﾞﾈ
15	0CW4A17526000	AF	DS		C	SENSOR HOLDER	ｾﾝｻｰﾎﾙﾀﾞｰ
16	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
17	0CW4116P492//	AL	EB		C	PAPER SUPPORT GUIDE	ﾂｳｼｶﾞｲﾄﾞ
18	0CW4A17327000	AD	DJ		C	PAPER SUPPORT HOLDER	ﾂｳｼｶﾞｲﾄﾞﾎﾙﾀﾞｰ
19	0CW4B10783000	AG	DX		C	GEAR HOLDING SPRING	ｷﾞｱ固定ｽﾌﾟﾘﾝｸﾞ
20	0CW4A17184000	AN	EG		C	BUNDLE-SUPPORTING BRACKET	束線押えﾌﾞﾗｹｯﾄ
21	0CW4060P027//	AB	DJ	N	C	SCREW	ﾋﾞｽ
22	0CW4F11566000	AG	DX		C	SUPPORT PLATE	ﾂｳｼﾌﾟﾚｰﾄ

9 束線押えｶﾊﾞｰ部 (Bundle Support Cover Assembly)



FCP08979

10 処理部 (Dispose Assembly)

NO.	PARTS CODE	PRICE RANK Ex.	PRICE RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	
1	0CW4A17390000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
2	0CW4H16454000	AE	DS		C	CABLE SENSOR	ｾﾝｻｰ束線
3	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
4	0CWXF21606140	AL	EB		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
5	0CW4A17328000	AD	DJ		C	BELT SENSOR LEVER	ﾍﾞﾙﾄｾﾝｻｰﾚﾊﾞｰ
6	0CW4A17383000	AY	FQ		B	TIMING BELT	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
7	0CW4A17392000	AE	DS		C	TENSION SPRING	ﾈｼﾞﾘﾊﾞﾈ
8	0CW4144P303//	AL	EB	N	D	DISPOSE COVER	処理ｶﾊﾞｰ
9	0CW4060P027//	AB	DJ	N	C	SCREW	ﾋﾞｽ
10	0CW4H16455000	AK	EB		C	CABLE TRAY	ﾄﾚｲ束線
11	0CW4K11067000	BA	FX		B	STEPPING MOTOR	ｽﾃｯﾋﾟﾝｸﾞﾓｰﾀｰ
12	0CWFC25034000	AB	DJ		C	SCREW W/WASHER(M3×6)	ﾊﾞﾈ付ﾅﾍﾞﾋﾞｽ
13	0CW4A18889010	AD	DJ		C	TRAY GUIDE FRONT	ﾄﾚｲｶﾞｲﾄﾞ前
14	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
15	0CW4A17273000	AD	DJ		C	GEAR(30T)	ｷﾞｱ
16	0CW4A17519000	AR	EQ		D	DISPOSE SUB COVER	処理ｻﾌﾞｶﾊﾞｰ
17	0CW4A17368000	AP	EQ		C	PULLEY(22T)	ﾌﾟｰﾘｰ
18	0CW4A17381000	AS	EQ		C	BUNDLE ROLLER LOWER	ﾀﾊﾞﾀﾞｼﾛｰﾗｰ下
19	0CW4A17567000	AD	DJ		C	CLIP SHAFT	軸ｸﾘｯﾌﾟ
20	0CW4A17572000	AE	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
21	0CW4A18319000	AD	DJ		C	PULLEY(22T)	ﾌﾟｰﾘｰ
22	0CW4A18334000	AC	DJ		C	FLANGE	ﾌﾗﾝｼﾞ
23	0CW4114P048B/	AU	EZ		C	SENSOR FLAG SUPPORT PLATE (INCH SERIES)	ｾﾝｻｰﾌﾗｸﾞ支板
	0CW4B10138010	AU	EZ		C	SENSOR FLAG SUPPORT PLATE (AB SERIES)	ｾﾝｻｰﾌﾗｸﾞ支板
24	0CW4A17329000	AE	DS		C	SENSOR FLAG	ｾﾝｻｰﾌﾗｸﾞ
25	0CW4A17402000	AC	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
26	0CW4H16464000	AN	EQ		C	CABLE EJECT MOTOR	ｲｼﾞｪｸﾄﾓｰﾀｰ束線
27	0CW4A17275000	AD	DJ		C	PULLEY(22T)	ﾌﾟｰﾘｰ
28	0CW4A18924010	AD	DJ		C	GUIDE TRAY REAR	ﾄﾚｲｶﾞｲﾄﾞ後
29	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
30	0CWFS21672000	AD	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
31	0CW4A17209000	AC	DJ		C	LEAF SPRING	板ﾊﾞﾈ
32	0CW4144P290//	AR	EQ	N	C	PAPER FEED GUIDE FRONT	処理ｶﾞｲﾄﾞ前
33	0CW4A17514000	AE	DS		C	BUNDLE ROLLER FLAG	ﾀﾊﾞﾛｰﾗｰﾌﾗｸﾞ
34	0CW4K11066000	BE	GN		B	STEPPING MOTOR	ｽﾃｯﾋﾟﾝｸﾞﾓｰﾀｰ
35	0CW4144P289//	AR	EQ	N	C	PAPER FEED GUIDE REAR	処理ｶﾞｲﾄﾞ後
36	0CW4A17314000	AH	DX		D	ADJUSTMENT RACK FRONT	整合ﾗｯｸ前
37	0CW4A18877000	AF	DS		D	ADJUSTMENT RACK COVER FRONT 1	整合ﾗｯｸｶﾊﾞｰ前 1
38	0CW4144P277//	AG	DX	N	D	ADJUSTMENT RACK COVER FRONT 2	整合ﾗｯｸｶﾊﾞｰ前 2
39	0CW4A17391000	AC	DJ		C	COMPRESSION SPRING	圧縮ﾊﾞﾈ
40	0CW4A17319000	AL	EB		C	ADJUSTMENT RACK REAR	整合ﾗｯｸ後
41	0CW4144P284//	AG	DX	N	D	ADJUSTMENT RACK COVER REAR	整合ﾗｯｸｶﾊﾞｰ後
42	0CW4A17212000	AE	DS		C	MICROSWITCH HOLDER	ﾏｲｸﾛｽｲｯﾁﾎﾙﾀﾞｰ
43	0CW4A17575010	AE	DS		D	MICROSWITCH COVER	ﾏｲｸﾛｽｲｯﾁｶﾊﾞｰ
44	0CW4H16449010	AM	EG		B	MICROSWITCH	ﾏｲｸﾛｽｲｯﾁ
45	0CW4B10779000	AF	DS		C	ADJUSTMENT-PLATE MYLAR REAR	整合ﾌﾟﾚｰﾄﾏｲﾗｰ後
46	0CW4B10778000	AF	DS		C	ADJUSTMENT-PLATE MYLAR FRONT	整合ﾌﾟﾚｰﾄﾏｲﾗｰ前
49	0CW4B10776000	AF	DS		C	ADJUSTMENT-RACK MYLAR	整合ﾗｯｸﾏｲﾗｰ
50	0CW4A17239000	AK	DX		C	PAWL BRACKET SHAFT	ﾎﾟｰﾙﾌﾞﾗｹｯﾄ軸
51	0CW4A17486000	AM	EG		C	MOTOR BRACKET	ﾓｰﾀｰﾌﾞﾗｹｯﾄ
52	0CW4A17191000	AF	DS		C	SENSOR BRACKET	ｾﾝｻｰﾌﾞﾗｹｯﾄ
53	0CW4F11564000	AW	FG		C	ADJUSTMENT BASE ASSY	整合ﾍﾞｰｽ
54	0CW4A17236000	AS	EQ		C	LOWER TB ROLLER SHAFT	下 TB ﾛｰﾗｰｼｬﾌﾄ
55	0CW4A17487000	AF	DS		C	P-LOCK BRACKET	P-ﾛｯｸﾌﾞﾗｹｯﾄ
56	0CW4A17193000	AG	DS		C	SIG SENSOR BRACKET	SIG ｾﾝｻｰﾌﾞﾗｹｯﾄ
57	0CW4B10852000	AE	DS		C	SUPPORT SHEET	補助ｼｰﾄ
60	0CW4A17196000	AH	DX		C	PULLEY SHAFT SUPPORT PLATE	ﾌﾟｰﾘｰ軸支板
61	0CW4A17483000	AL	EB		C	STAY	整合ｽﾃｰ
62	0CW4A17266000	AE	DS		C	SENSOR SUPPORT PLATE	ｾﾝｻｰ支板
63	0CW4B10086000	AL	EB		C	WEIGHT FLAPPER INSIDE	排紙ｳｪｲﾄ中
64	0CW4B10144000	AE	DJ		C	WEIGHT FLAPPER SHEET INSIDE	排紙ｳｪｲﾄﾏｲﾗｰ中
65	0CW4B10085000	AK	EB		C	WEIGHT FLAPPER FRONT	排紙ｳｪｲﾄ前
66	0CW4B10156000	AE	DJ		C	WEIGHT FLAPPER SHEET FRONT	排紙ｳｪｲﾄﾏｲﾗｰ前
67	0CW4B10087000	AK	EB		C	WEIGHT FLAPPER REAR	排紙ｳｪｲﾄ後
68	0CW4B10082000	AF	DS		C	WEIGHT FLAPPER SHEET REAR	排紙ｳｪｲﾄﾏｲﾗｰ後
69	0CW4144P053//	AP	EQ	N	C	PAWL SHEET HOLDER	爪ｼｰﾄﾎﾙﾀﾞｰ
70	0CW4144P408//	AF	DS	N	C	PAWL SHEET	爪ｼｰﾄ
501	0CWXB47401007	AB	DJ		C	SCREW TAPPING(M4×10)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
502	0CWXD32200122	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
503	0CWXD32200102	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
504	0CWXB12400606	AB	DJ		C	SCREW(M4×12)	ﾋﾞｽ

10 処理部 (Dispose Assembly)



11 搬送部 (Paper Feeder Assembly)

NO.	PARTS CODE	PRICE RANK Ex.	PRICE RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	
1	0CW4A17278000	AC	DJ		C	FLANGE	ﾌﾗﾝｼﾞ
2	0CW4A17281000	AD	DJ		C	PULLEY(20T)	ﾌﾟｰﾘｰ
3	0CW4A17337000	AE	DS		C	PAPER AUXILIARY GUIDE	紙補助ｶﾞｲﾄﾞ
5	0CW4A17401000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
6	0CW4109P231//	AD	DJ		C	PAWL FRONT	爪前
7	0CW4109P232//	AD	DJ		C	PAWL REAR	爪後
8	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
9	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
10	0CW4A17271000	AP	EQ		C	PULLEY(40T)	ﾌﾟｰﾘｰ
11	0CW4A17272000	AN	EQ		C	PULLEY(18T/29T)	ﾌﾟｰﾘｰ
12	0CW4A17274000	AD	DJ		C	GEAR(20T/32T)	ｷﾞｱ
13	0CW4A17276000	AC	DJ		C	FLANGE	ﾌﾗﾝｼﾞ
14	0CW4A17279000	AD	DJ		C	GEAR(20T)	ｷﾞｱ
15	0CW4A17280000	AD	DJ		C	GEAR(30T/20T)	ｷﾞｱ
16	0CW4A17330000	AD	DJ		C	SENSOR FLAG	ｾﾝｻｰﾌﾗｸﾞ
17	0CW4A17331000	AD	DJ		C	CAM	ｶﾑ
18	0CW4A17332000	AC	DJ		C	LINK ARM 1	ﾘﾝｸｱｰﾑ 1
19	0CW4A17346000	AC	DJ		C	PADDLE SHAFT SUPPORT	ﾊﾟﾄﾞﾙ軸台
20	0CW4A17347000	AD	DJ		C	LINK ARM 2	ﾘﾝｸｱｰﾑ 2
21	0CW4A17348000	AD	DJ		C	LINK ARM 3	ﾘﾝｸｱｰﾑ 3
22	0CW4A17351000	AD	DJ		C	PULLEY(24T)	ﾌﾟｰﾘｰ
23	0CW4A17366000	AE	DJ		C	LINK ARM 4	ﾘﾝｸｱｰﾑ 4
24	0CW4114P813//	AF	DS		C	COMPRESSION SPRING	圧縮ﾊﾞﾈ
25	0CW4A17339000	AC	DJ		C	FLANGE	ﾌﾗﾝｼﾞ
26	0CW4A17372000	AH	DX		C	SAFETY GUIDE REAR 1	ｾｰﾌﾃｨｶﾞｲﾄﾞ後 1
27	0CWFS21672000	AD	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
28	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
29	0CWXF21604940	AL	EB		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
30	0CWXF21607640	AN	EG		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
31	0CW4A17194000	AR	EQ		C	PAPER OUTLET GUIDE UPPER	紙出口ｶﾞｲﾄﾞ前
32	0CW4A17427000	AT	EZ		C	ELIMINATOR STATIC CHARGE	除電ｼﾝ
33	0CW4114P352//	AH	DX	N	C	SAFETY GUIDE REAR 2	ｾｰﾌﾃｨｶﾞｲﾄﾞ後 2
34	0CW4A17406000	AH	DX		C	PAPER OUTLET ROLLER	紙出口ｺﾛ
35	0CW4113P643B/	AR	EQ		C	PAPER OUTLET ROLLER PLATE	紙出口ｺﾛ支板
37	0CW4A17531000	AK	DX		C	PAPER OUTLET ROLLER 1	紙出口ﾛｰﾗｰ 1
38	0CW4116P759//	AN	EG		C	WEIGHT FLAPPER ROLLER	排紙ﾛｰﾗｰ
39	0CW4A17352000	AC	DJ		C	PADDLE ROLLER HOLDER 1	ﾊﾟﾄﾞﾙﾛｰﾗｰﾎﾙﾀﾞｰ 1
41	0CW4A17513000	AD	DJ		C	SENSOR FLAG CAM	ｾﾝｻｰﾌﾗｸﾞｶﾑ
42	0CW4A17585000	AE	DJ		C	FLANGE	ﾌﾗﾝｼﾞ
43	0CW4A17333000	AN	EG		C	PAPER GUIDE LOWER	紙ｶﾞｲﾄﾞ下
44	0CW4A17283000	AC	DJ		C	GEAR(14T)	ｷﾞｱ
45	0CW4A17282000	AC	DJ		C	GEAR(14T)	ｷﾞｱ
46	0CW4A17286000	AE	DS		C	ROLLER HOLDER FRONT 1	ﾛｰﾗｰ支持ﾌﾞﾛｯｸ前 1
47	0CW4A17345000	AE	DJ		C	ROLLER HOLDER FRONT 2	ﾛｰﾗｰ支持ﾌﾞﾛｯｸ前 2
48	0CW4A17379000	AS	EQ		C	BUNDLE ROLLER UPPER	束ﾛｰﾗｰ上
49	0CW4113P352//	AG	DX		C	SAFETY GUIDE FRONT	ｾｰﾌﾃｨｶﾞｲﾄﾞ前
50	0CW4A17285000	AE	DS		C	ROLLER HOLDER REAR 1	ﾛｰﾗｰ支持ﾌﾞﾛｯｸ後 1
51	0CW4A17344000	AE	DJ		C	ROLLER HOLDER REAR 2	ﾛｰﾗｰ支持ﾌﾞﾛｯｸ後 2
52	0CW4A17341000	AH	DX		C	SAFETY GUIDE	ｾｰﾌﾃｨｶﾞｲﾄﾞ
53	0CW4B10846000	AD	DJ		C	JUMP STOCK	ｼﾞｬﾝﾌﾟｽﾄｯｸ
56	0CW4B10591000	AF	DS		C	WASHER	ﾜｯｼｬｰ
57	0CW4139P139//	AR	FG		C	EXIT ROLLER SHAFT	出紙ﾛｰﾗｰｼｬﾌﾄ
58	0CW4A17192000	AE	DS		C	CAM SENSOR BRACKET	ｶﾑｾﾝｻｰﾌﾞﾗｹｯﾄ
59	0CW4F11565000	AP	EQ		C	TRANSFER FRAME REAR	搬送ﾌﾚｰﾑ後
60	0CW4A17234000	AR	EQ		C	CAM SHAFT	ｶﾑｼｬﾌﾄ
61	0CW4A18320000	AC	DJ		C	SR-PAD	SRﾊﾟｯﾄﾞ
62	0CW4A17202000	AK	DX		C	TRANSFER FRAME FRONT	搬送ﾌﾚｰﾑ前
63	0CW4A17237000	AT	EZ		C	PDL SHAFT	PDL ｼｬﾌﾄ
64	0CW4110P362//	AD	DJ		C	DUMMY PADDLE HOLDER	ﾀﾞﾐｰﾊﾟﾄﾞﾙﾎﾙﾀﾞｰ
65	0CW4B10140000	AN	EQ		C	PADDLE SMALL	ﾊﾟﾄﾞﾙ小
66	0CW4B10149000	AD	DJ		C	PADDLE HOLDER	ﾊﾟﾄﾞﾙﾎﾙﾀﾞｰ
67	0CW4A17238000	AR	EQ		C	ROLLER SHAFT UPPER	ﾛｰﾗｰ軸上
68	0CW4B10111000	AE	DS		C	PDL SMALLNESS HOLDER REAR	ﾊﾟﾄﾞﾙ小ﾎﾙﾀﾞｰ後
69	0CW4A18888000	AN	EG		C	PADDLE RUBBER	ﾊﾟﾄﾞﾙﾗﾊﾞｰ
70	0CW4114P401//	AE	DJ		C	TENSION SPRING (AB SERIES)	引張ﾊﾞﾈ
	0CW4134P401//	AE	DS		C	TENSION SPRING (INCH SERIES)	引張ﾊﾞﾈ
71	0CW4A17384000	AN	EG		C	PADDLE	ﾊﾟﾄﾞﾙ
501	0CWXD32200102	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
502	0CWXB47401007	AB	DJ		C	SCREW TAPPING(M4×10)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ

11 搬送部 (Paper Feeder Assembly)



12 折り部 1/3 (Fold Assembly 1/3)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
6	0CW4A17299000	AG	DX		C	SADDLE CAM FRONT	ｻﾄﾞﾙｶﾑ前
11	0CW4A17357000	AD	DJ		C	PULLEY(27T)	ﾌﾟｰﾘｰ
17	0CW4A17363000	AH	DX		C	SADDLE CAM REAR	ｻﾄﾞﾙｶﾑ後
18	0CW4A17364000	AL	EB		C	GEAR(24T)	ｷﾞｱ
20	0CW4A17376000	AF	DS		C	GEAR(16T/42T)	ｷﾞｱ
21	0CW4A17377000	AD	DJ		C	GEAR(21T)	ｷﾞｱ
22	0CW4A17385000	BN	HZ		C	FOLD ROLLER	ﾛｰﾗｰ
25	0CW4A17388000	AE	DS		C	TENSION SPRING	引張ﾊﾞﾈ
30	0CW4A17533000	AC	DJ		C	SPRING HOOK	ﾊﾞﾈﾌｯｸ
32	0CW4A17552000	AF	DS		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
33	0CW4A17566000	AD	DJ		C	CLIP SHAFT	軸ｸﾘｯﾌﾟ
36	0CW4A17573000	AE	DS		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
38	0CW4A18330000	AD	DJ		C	GEAR(18T)	ｷﾞｱ
40	0CW4A18332000	AR	EQ		C	PAPER DELIVERY GUIDE LOWER	排紙ｶﾞｲﾄﾞ下
42	0CW4K14040000	BB	GD		B	ELECTROMAGNETIC CLUTCH	ﾃﾞﾝｼﾞｸﾗｯﾁ
44	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
46	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
48	0CWFS21672000	AD	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
50	0CW4A17476000	AC	DJ		C	PLATE SPRING	板ﾊﾞﾈ
54	0CWWG85362000	AH	DX		B	PHOTO INTERRUPTER(TLP1241)	ﾌｫﾄｲﾝﾀﾗﾌﾟﾀ
72	0CW4A17525000	AD	DJ		C	ROLLER	ｺﾛ
73	0CW4A17256000	AN	EG		C	ROLLER SHAFT	ﾛｰﾗｰ軸
74	0CW4A17504000	AF	DS		C	HARNESS DUCT	ﾊｰﾈｽﾀﾞｸﾄ
75	0CW4A17485000	AK	DX		C	TENSION BRACKET	ﾃﾝｼｮﾝﾌﾞﾗｹｯﾄ
76	0CW4113K034//	AU	FG		C	FRAME REAR	ﾌﾚｰﾑ後
77	0CW4A17477000	AN	EQ		C	TOP BRACKET	ﾄｯﾌﾟﾌﾞﾗｹｯﾄ
78	0CW4F11568010	AY	FQ		C	FRAME FRONT	ﾌﾚｰﾑ前
79	0CW4A17227000	AT	EZ		C	SHAFT CAM	ｶﾑｼｬﾌﾄ
80	0CW4A18323000	AC	DJ		C	GUIDE PAD	ｶﾞｲﾄﾞﾊﾟｯﾄﾞ
81	0CW4135P439//	AF	DJ		C	SPRING	ｽﾌﾟﾘﾝｸﾞ
82	0CWPW060050//	AA	DD		C	WASHER	ﾎﾞﾘｽﾗｲﾀﾞｰ
83	0CWXD21100502	AC	DJ		C	E-RING	Eﾘﾝｸﾞ
502	0CWXD32200102	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
505	0CWXD32300162	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

12 折り部 1/3 (Fold Assembly 1/3)



FCP08982

13 折り部 2/3 (Fold Assembly 2/3)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4A17177000	AG	DS		C	SWING GUIDE FRONT	ﾖｳﾄﾞｳｶﾞｲﾄﾞ前
2	0CW4A17178000	AG	DS		C	SWING GUIDE REAR	ﾖｳﾄﾞｳｶﾞｲﾄﾞ後
4	0CW4A17295000	AD	DJ		C	CAM FRONT	ｶﾑ前
5	0CW4A17296000	AD	DJ		C	CAM REAR	ｶﾑ後
7	0CW4A17335000	AN	EG		C	PULLEY(36T)	ﾌﾟｰﾘｰ
8	0CW4A17339000	AC	DJ		C	FLANGE	ﾌﾗﾝｼﾞ
10	0CW4A17350000	AC	DJ		C	SADDLE SLIDER	ｻﾄﾞﾙｽﾗｲﾀﾞｰ
15	0CW4A17361000	AD	DJ		C	ROLLER HOLDER	ﾛｰﾗｰﾎﾙﾀﾞｰ
24	0CW4A17387000	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
30	0CW4A17533000	AC	DJ		C	SPRING HOOK	ﾊﾞﾈﾌｯｸ
31	0CW4A17551000	AD	DJ		C	WASHER	ﾜｯｼｬｰ
33	0CW4A17566000	AD	DJ		C	CLIP SHAFT	軸ｸﾘｯﾌﾟ
34	0CW4A17567000	AD	DJ		C	CLIP SHAFT	軸ｸﾘｯﾌﾟ
36	0CW4A17573000	AE	DS		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
37	0CW4A18329000	AC	DJ		C	LINK ROLLER	ﾘﾝｸｺﾛ
39	0CW4A18331000	AD	DJ		C	GEAR(17T)	ｷﾞｱ
43	0CW4S19048000	AC	DJ		C	SCREW STEPPED	段ﾋﾞｽ
44	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
46	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
55	0CW4A18327000	AL	EB		C	SPRING LEAF	板ﾊﾞﾈ
56	0CW4A18326000	AK	DX		C	SPRING LEAF	板ﾊﾞﾈ
57	0CW4A17480000	AP	EQ		C	DELIVERY PAPER GUIDE	排紙ｶﾞｲﾄﾞ
58	0CW4A18324000	AE	DS		C	REINFORCEMENT PLATE	補強板
59	0CW4A17322000	AD	DJ		C	FOLD ROLLER	折りﾛｰﾗｰ
60	0CW4A17481000	AE	DS		C	DELIVERY ROLLER HOLDER	排紙ｺﾛﾎﾙﾀﾞｰ
68	0CW4A17297000	AC	DJ		C	LINK ROLLER	ﾘﾝｸｺﾛ
71	0CW4A17228010	AC	DJ		C	LINK SHAFT	ﾘﾝｸ軸
73	0CW4109P449／／	AD	DJ		C	TENSION SPRING	引張ﾊﾞﾈ
74	0CW4A17298000	AF	DS		C	SADDLE ROLLER	ｻﾄﾞﾙｺﾛ
75	0CW4F11569000	AK	DX		C	OPENER PLATE FRONT	ｵｰﾌﾟﾅ板前
76	0CW4F11570000	AK	DX		C	OPENER PLATE REAR	ｵｰﾌﾟﾅ板後
77	0CW4A17181000	AG	DX		C	COVER LINK	ｶﾊﾞｰﾘﾝｸ
78	0CW4A17242000	AU	FG		C	F-IN CAM SHAFT	F-IN ｶﾑ軸
79	0CW4A18325000	AN	EG		C	BASE SPRING PLATE	板ﾊﾞﾈ
80	0CW4A17203010	AL	EB		C	BASE BRACKET	ﾍﾞｰｽﾌﾞﾗｹｯﾄ
81	0CWXD21100402	AC	DJ		C	E-RING	E ﾘﾝｸﾞ
82	0CWHW050FZS00	AB	DJ		C	WASHER	ﾜｯｼｬｰ
83	0CW4A18328000	AC	DJ		C	LINK PAD	ﾘﾝｸﾊﾟｯﾄﾞ
84	0CW4A17180000	AN	EG		C	SADDLE COVER	ｻﾄﾞﾙｶﾊﾞｰ
85	0CW4A17179000	AV	FG		C	SADDLE PLATE	ｻﾄﾞﾙ板
86	0CW4A17188000	AF	DS		C	SADDLE PLATE SUB	ｻﾄﾞﾙ板ｻﾌﾞ
87	0CW4113K158A／	AS	EQ		C	LEVER ASSY	ﾚﾊﾞｰ Assy
88	0CW030060FZBi	AA	DD		C	SCREW(3×6)	ﾋﾞｽ
501	0CWXB12401005	AB	DJ		C	SCREW(M4×10)	ﾋﾞｽ
503	0CWXD32200142	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

13 折り部 2/3 (Fold Assembly 2/3)



14 折り部 3/3 (Fold Assembly 3/3)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
3	0CW4A17290000	AE	DS		C	GEAR(8T)	ｷﾞｱ
9	0CW4A17340000	AG	DX		C	GEAR(16T)	ｷﾞｱ
12	0CW4A17358000	AP	EQ		C	GEAR(16T/41T)	ｷﾞｱ
13	0CW4A17359000	AK	DX		C	GEAR(15T/38T)	ｷﾞｱ
14	0CW4A17360000	AK	DX		C	GEAR(24T)	ｷﾞｱ
16	0CW4A17362000	AL	EB		C	GEAR(24T)	ｷﾞｱ
19	0CW4A17365000	AF	DS		C	GEAR(16T)	ｷﾞｱ
23	0CW4A17386000	AE	DS		C	COMPRESSION SPRING	圧縮ﾊﾞﾈ
26	0CW4A17389000	AG	DX		C	TENSION SPRING	引張ﾊﾞﾈ
27	0CW4A17403000	AE	DS		C	TENSION SPRING	引張ﾊﾞﾈ
28	0CW4A17404000	AV	FG		C	ROLLER	ﾛｰﾗｰ
29	0CW4A17530000	AD	DJ		C	PULLEY(27T)	ﾌﾟｰﾘｰ
34	0CW4A17567000	AD	DJ		C	CLIP SHAFT	軸ｸﾘｯﾌﾟ
35	0CWFC21175000	AC	DJ		C	SCREW	ﾋﾞｽ
41	0CW4H16456000	AN	EG		C	CABLE CONNECTING	中継束線
44	0CWFC22120000	AC	DJ		C	SCREW(M4×7)	ﾋﾞｽ
45	0CW4H16450000	AT	EZ		E	LED PWB UNIT	LED 回路基板
46	0CWFC25827000	AE	DJ		C	CLIP	ｸﾘｯﾌﾟ
47	0CWFS21615000	AS	EZ		C	BALL BEARING	ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ
48	0CWFS21672000	AD	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
49	0CWXF21607240	AN	EG		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
51	0CW4A17536000	AC	DJ		C	SHAFT CLIP	軸ｸﾘｯﾌﾟ
52	0CW4A17544000	AR	EQ		C	FOLD ROLLER	折りﾛｰﾗｰ
53	0CW4A17545000	AQ	EQ		C	FOLD ROLLER SUB	折りﾛｰﾗｰｻﾌﾞ
61	0CW4A17187000	AK	EB		C	FOLD ROLLER GUIDE 1	折りﾛｰﾗｰｶﾞｲﾄﾞ 1
62	0CW4A17309000	AE	DJ		C	GUIDE HOLDER FRONT 1	ｶﾞｲﾄﾞﾎﾙﾀﾞｰ前 1
63	0CW4A17310000	AE	DJ		C	GUIDE HOLDER REAR 1	ｶﾞｲﾄﾞﾎﾙﾀﾞｰ後 1
64	0CW4A17186010	AL	EB		C	FOLD ROLLER GUIDE 2	折りﾛｰﾗｰｶﾞｲﾄﾞ 2
65	0CW4A17311000	AE	DJ		C	GUIDE HOLDER FRONT 2	ｶﾞｲﾄﾞﾎﾙﾀﾞｰ前 2
66	0CW4A17312000	AE	DJ		C	GUIDE HOLDER REAR 2	ｶﾞｲﾄﾞﾎﾙﾀﾞｰ後 2
67	0CW4A17207000	AR	EQ		C	PAPER GUIDE UPPER	ﾂｳｼｶﾞｲﾄﾞ上
69	0CW4A17204000	AM	EG		C	PAPER GUIDE LOWER	ﾂｳｼｶﾞｲﾄﾞ下
70	0CW4A18322000	AC	DJ		C	LEAF EARTH SPRING	ｱｰｽ板ﾊﾞﾈ
71	0CW4A17470000	AP	EQ		C	SUB FRAME FRONT	ｻﾌﾞﾌﾚｰﾑ前
72	0CW4A17254000	AX	FQ		C	FOLD SHAFT 1	折り部軸 1
73	0CW4A17255000	AY	FQ		C	FOLD SHAFT 2	折り部軸 2
74	0CW4A17175000	AF	DS		C	FOLD SUPPORT ROLLER PLATE FRONT	折りﾛｰﾗｰ支持板前
75	0CW4A17176000	AF	DS		C	FOLD SUPPORT ROLLER PLATE REAR	折りﾛｰﾗｰ支持板後
76	0CW4A17492000	AF	DS		C	BANDAGE COVER	目隠しｶﾊﾞｰ
502	0CWXD32200102	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
504	0CWXD32300142	AD	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
506	0CWXD32300182	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

14 折り部 3/3 (Fold Assembly 3/3)



FCP08984

15 ｽﾃｲﾌﾟﾙ部 1/2 (Staple Assembly 1/2)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4A18206000	AD	DJ		C	TENSION ROLLER	ﾃﾝｼｮﾝﾛｰﾗｰ
2	0CW4A18207000	AN	EQ		C	TENSION SPRING	引張ﾊﾞﾈ
3	0CW4A18214000	AG	DX		D	MOTOR COVER	ﾓｰﾀｰｶﾊﾞｰ
5	0CW4A18217000	AE	DS		C	CAM STOPPER 1	ｶﾑｽﾄｯﾊﾟ 1
10	0CW4A17592000	AE	DJ		C	TORSION SPRING	ﾈｼﾞﾘﾊﾞﾈ
11	0CW4A18225000	AD	DJ		C	PULLEY(38T)	ﾌﾟｰﾘｰ
13	0CW4A18904000	AF	DS		C	STAPLE MOVABLE KNOB	ｽﾃｨﾌﾟﾙ移動ﾉﾌﾞ
17	0CW4A18905000	AH	DX		C	JAM CLEANING KNOB	JAM 処理ﾉﾌﾞ
18	0CWFC30661000	AC	DJ		C	CLIP	ｸﾘｯﾌﾟ
19	0CWFC15034000	AC	DJ		C	SCREW W/WASHER(M3×6)	ﾊﾞﾈ付ﾅﾍﾞﾋﾞｽ
21	0CW4S19076000	AC	DJ		C	SCREW(M3×8)	ﾋﾞｽ
22	0CW4A18238000	AR	EQ		D	FRONT COVER	前ｶﾊﾞｰ
23	0CW4A18907000	AH	DX		D	HANDLE COVER	ﾄｯﾃｶﾊﾞｰ
26	0CW4A18240000	AQ	EQ		C	PAPER COVER	紙ｶﾞｲﾄﾞ
27	0CW4B10743000	AE	DJ		C	COMPRESSION SPRING	圧縮ﾊﾞﾈ
28	0CW4A17581000	AF	DS		C	PAPER GUIDE SUB	紙ｶﾞｲﾄﾞ板ｻﾌﾞ
29	0CW4A17584000	AD	DJ		C	MARKER PIN	表示ﾏｰｶｰﾋﾟﾝ
31	0CW4A17583000	AD	DJ		C	GEAR(42T)	ｷﾞｱ
32	0CW4F11679000	AF	DS		C	TENSION PLATE	ﾃﾝｼｮﾅ板
33	0CWFC30779000	AC	DJ		C	SCREW(M3×6)	ﾋﾞｽ
35	0CW4A18210000	AD	DJ		C	PIN SLIDE	ｽﾗｲﾄﾞﾋﾟﾝ
36	0CW4A18198000	AC	DJ		C	ROLLER	ｺﾛ
41	0CW4H16506000	AW	FG		C	CABLE STAPLER 2	ｽﾃｨﾌﾟﾗ束線 2
42	0CW4K11070000	BE	GN		B	STEPPING MOTOR	ｽﾃｯﾋﾟﾝｸﾞﾓｰﾀｰ
43	0CW4B10754000	AE	DJ		C	FLANGE	ﾌﾗﾝｼﾞ
44	0CW4B10744000	AE	DJ		C	PULLEY	ﾌﾟｰﾘｰ
45	0CW4S10280000	AD	DS		C	TENSION SPRING	引張ﾊﾞﾈ
46	0CW4F12053000	AH	DX		C	PLATE STAPLE TENSION	ｽﾃｲﾌﾟﾙﾃﾝｼｮﾅ板
47	0CW4B10746000	AD	DJ		C	TENSION ROLLER	ﾃﾝｼｮﾅﾛｰﾗｰ
48	0CW4A18232000	AF	DS		C	GEAR(18T/66T)	ｷﾞｱ
49	0CWXF21804070	AQ	EQ		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
50	0CW4B10742000	AF	DS		C	GUIDE	ｶﾞｲﾄﾞ
51	0CW4A17590000	AC	DJ		C	STAPLE GUIDE PAD	ｽﾃｲﾌﾟﾙｶﾞｲﾄﾞﾊﾟｯﾄﾞ
52	0CWRA22452000	AC	DJ		C	BUSHING	ﾌﾞｯｼﾝｸﾞ
53	0CW4B10740000	AE	DS		C	GEAR(16/29T)	ｷﾞｱ
54	0CW040080FWWS	AC	DJ	N	C	SCREW	ﾋﾞｽ
55	0CW4A18881000	AF	DS		C	BUNDLE-WIRE GUIDE	ﾊﾞﾝﾄﾞﾙﾜｲﾔｰｶﾞｲﾄﾞ
56	0CW4A18211000	AD	DJ		C	FPC GUIDE	FPC ｶﾞｲﾄﾞ
57	0CW4A18227000	AP	EQ		B	BELT	ﾍﾞﾙﾄ
58	0CW4135Q401／／	AE	DJ	N	C	STAPLE DRIVER SHEET	ｽﾃｲﾌﾟﾙﾄﾞﾗｲﾊﾞｰﾏｲﾗｰ
501	0CWXD21100502	AC	DJ		C	E-RING	E ﾘﾝｸﾞ
502	0CWXB12300605	AB	DJ		C	SCREW(M3×6)	ﾋﾞｽ
503	0CWXB47401007	AB	DJ		C	SCREW TAPPING(M4×10)	ﾀｯﾋﾟﾝｸﾞﾋﾞｽ
504	0CWXD21100642	AC	DJ		C	E-RING	E ﾘﾝｸﾞ
505	0CWXB12400607	AB	DJ		C	SCREW(M4×6)	ﾋﾞｽ
507	0CWXD32300142	AD	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

15 ｽﾃｲﾌﾟﾙ部 1/2 (Staple Assembly 1/2)



16 ｽﾃｲﾌﾟﾙ部 2/2 (Staple Assembly 2/2)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
4	0CW4A18215000	AF	DS		C	COUPLING FRAME	ｶｯﾌﾟﾘﾝｸﾞﾍﾞｰｽ
6	0CW4A18218000	AF	DS		C	COUPLING	ｶｯﾌﾟﾘﾝｸﾞ
7	0CW4A18219000	AF	DS		C	COMPRESSION SPRING	圧縮ﾊﾞﾈ
8	0CW4A17591000	AF	DS		C	STAPLE GUIDE ROLLER HOLDER	ｽﾃｨﾌﾟﾙｶﾞｲﾄﾞｺﾛﾎﾙﾀﾞｰ
9	0CW4A17589000	AD	DJ		C	STAPLE GUIDE ROLLER	ｽﾃｨﾌﾟﾙｶﾞｲﾄﾞｺﾛ
12	0CW4A18226000	AE	DJ		C	GEAR(36T/38T)	ｷﾞｱ
14	0CW4A18229000	AF	DS		C	GEAR(42T/32T)	ｷﾞｱ
15	0CW4A18230000	AE	DJ		C	PULLEY(24T)	ﾌﾟｰﾘｰ
16	0CWXF21309000	AS	EZ		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
20	0CWFC25035000	AC	DJ		C	SCREW W/WASHER(M3×6)	ﾊﾞﾈ付ﾅﾍﾞﾋﾞｽ
24	0CW4A18265000	AE	DS		D	SIDE COVER RIGHT	ｻｲﾄﾞｶﾊﾞｰ右
25	0CW4A18264000	AE	DS		D	SIDE COVER LEFT	ｻｲﾄﾞｶﾊﾞｰ左
30	0CW4A18263000	AE	DS		D	GEAR COVER	ｷﾞｱｶﾊﾞｰ
34	0CW4A18884000	BF	GN		E	STAPLE CARTRIDGE UNIT	ｽﾃｨﾌﾟﾙｶｰﾄﾘｯｼﾞﾕﾆｯﾄ
37	0CW4099K310//	AM	EG	N	E	STAPLER BASE PWB ASSEMBLY	ｽﾃｨﾌﾟﾗﾍﾞｰｽ回路基板
38	0CW4099K312//	AP	EQ	N	E	STAPLER IN PWB ASSEMBLY	ｽﾃｨﾌﾟﾗｲﾝ回路基板
39	0CW4H16504000	AK	DX		C	CABLE STAPLER	ｽﾃｨﾌﾟﾗ束線
40	0CW4H16505000	AH	DX		C	CABLE STAPLER 1	ｽﾃｨﾌﾟﾗ束線 1
42	0CWXF21309000	AS	EZ		B	BELT TIMING	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
501	0CWXD21100502	AC	DJ		C	E-RING	E ﾘﾝｸﾞ
504	0CWXD21100642	AC	DJ		C	E-RING	E ﾘﾝｸﾞ
506	0CWXD32300122	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ
508	0CWXD32200142	AC	DJ		C	PIN DOWEL	平行ﾋﾟﾝ

16 ｽﾃｲﾌﾟﾙ部 2/2 (Staple Assembly 2/2)



FCP08986

17 梱包 & 付属品 (Packing Material & Accessories)

NO.	PARTS CODE	PRICE RANK Ex.	PRICE RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	
1	0CW4144P901//	BG	GT	N	D	PACKING CASE	(JAPAN) ﾊﾟｯｷﾝｸﾞｹｰｽ
	0CW4144P902//	BG	GT	N	D	PACKING CASE	(Other Countries) ﾊﾟｯｷﾝｸﾞｹｰｽ
2	0CW4144K600//	BP	LP	N	D	STAPLE PAD	ｱﾄﾞ
3	0CW4144P908//	AL	EB	N	D	PACKING ADD SPC	SPC ﾎﾞｰﾄﾞﾊﾟｯｷﾝｸﾞ
4	0CW2216P524//	AE	DS		D	VINYL BAG A(HOLE)	ﾋﾞﾆｰﾙ袋 A
7	0CW4144P909//	AE	DJ	N	D	PACKING ADD PAD	PAD ﾎﾞｰﾄﾞﾊﾟｯｷﾝｸﾞ
8	0CW4088P220//	AQ	EQ		D	VINYL BAG	ｶﾞｾﾞｯﾄ袋
9	0CW2158P380//	AE	DJ		D	HARNESS PACKING	ﾊｰﾈｽﾊﾟｯｷﾝｸﾞ
11	0CW4099P903//	AL	EB		D	JOINT	ﾊﾟﾅｼﾞｮｲﾝﾄ
12	0CW4144P900//	BQ	LP	N	D	PACKING PALLET	ﾊﾟﾚｯﾄ
13	0CW4110Q165//	AL	EB	N	D	PACKING ADD	ﾊﾟｯｷﾝｸﾞｱﾄﾞ
14	0CW2214P358//	AB	DJ		D	VINYL BAG(HS-1)	ﾋﾞﾆｰﾙ袋
15	0CW4134P420//	AF	DS		D	OPERATION MANUAL	設置手順書
16	0CW61637/////	AA	DJ	N	D	VINYL BAG C	ﾋﾞﾆｰﾙ袋 C
17	0CW4144P364//	AF	DS	N	D	PUNCH LABEL RSDF	ﾊﾟﾝﾁﾗﾍﾞﾙ RSDF
18	0CW4144P363//	AF	DS	N	D	PUNCH LABEL FIN	ﾊﾟﾝﾁﾗﾍﾞﾙ FIN
19	0CW4144P362//	AF	DS	N	D	STAPLE LABEL RSDF	ｽﾃｲﾌﾟﾙﾗﾍﾞﾙ RSDF
20	0CW4144P361//	AF	DS	N	D	STAPLE LABEL FIN	ｽﾃｲﾌﾟﾙﾗﾍﾞﾙ FIN
21	0CW040180NBP/	AC	DJ	N	C	SCREW	ﾋﾞｽ
22	0CWSCR00045//	AC	DJ		C	SCREW	ﾋﾞｽ
23	0CW4099P913//	AC	DJ		D	PACKING MAT SD	ﾊﾟｯｷﾝｸﾞﾏｯﾄ
24	0CW4144P911//	AE	DS	N	D	PACKING ADD CVR	CVR ﾎﾞｰﾄﾞﾊﾟｯｷﾝｸﾞ
25	0CW4144P912//	AE	DJ	N	D	PACKING ADD	CVR ｱﾄﾞ
26	0CW4144P910//	AQ	EQ	N	D	PACKING ADD DP	DP ﾎﾞｰﾄﾞﾊﾟｯｷﾝｸﾞ
27	0CW4099P912//	AD	DJ		D	MIRROR PAD(85×85)	ﾐﾗﾏｯﾄ
28	0CW4099P911//	AC	DJ		D	MIRROR PAD(80×80)	ﾐﾗﾏｯﾄ

17 梱包 & 付属品 (Packing Material & Accessories)



18 梱包 & 付属品 (Packing Material & Accessories)[AR-PN1]

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW2111P021//	AC	DJ		D	VINYL BAG A	ﾎｰﾙｽﾙｰ袋 A
2	0CW1020K435//	AY	FQ		D	PAD SET	ﾊﾟｯﾄ組品 SH
3	0CW1020P832//	AF	DS		D	VINYL BAG E	ﾎﾞﾘ袋 E
4	0CW1020K375//	AH	DX		D	ASM-I/F HARNESS	ASM-I/F ﾊｰﾈｽ
5	0CW1020P827//	AQ	EQ		D	PACKING CASE	ﾊﾟｯｷﾝｸﾞｹｰｽ
6	0CW1020K374//	AN	EG		D	ASM-POWER HARNESS	ASM-POWER ﾊｰﾈｽ
7	0CW040060FZTW	AC	DJ		C	SCREW	ﾋﾞｽ
8	0CW616371////	AA	DJ		D	VINYL BAG C(80×120)	ﾋﾞﾆｰﾙ袋 C
10	0CW4B10489000	AF	DS		D	LABEL	ﾊﾟﾝﾁｸｽﾞｽﾃﾗﾍﾞﾙ
11	0CW4B10488000	AF	DS		D	PUNCH POSITION LABEL(2-HOLE) (FOR JAPAN AND EUROPE)	ﾊﾟﾝﾁ位置ﾗﾍﾞﾙ
12	0CW4B10485000	AF	DS		D	PUNCH POSITION LABEL(2/3-HOLE) (FOR U.S.A,CANADA,AUSTRALIA AND NEW ZEALAND)	ﾊﾟﾝﾁ位置ﾗﾍﾞﾙ
13	0CW4B10486000	AF	DS		D	PUNCH POSITION LABEL(4-HOLE) (FOR EUROPE)	ﾊﾟﾝﾁ位置ﾗﾍﾞﾙ
100	0CW1020P711B/	AK	DX		D	INST. MANUAL	ﾊﾟﾝﾁﾕﾆｯﾄ設置手順書ﾍﾟﾗ

18 梱包 & 付属品 (Packing Material & Accessories)[AR-PN1]



FCP08988

19 DC ｺﾝﾄﾛｰﾗｰ回路基板 (DC CONTROLLER PWB ASSEMBLY)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW323000048//	AH	DX	N	B	EP-ROM(S-93C46BD0I-D8S1G)	EP-ROM
2	0CWE312001475	AF	DS		B	TRANSISTOR(2SK3495)	ﾄﾗﾝｼﾞｽﾀｰ
3	0CWE321000945	AT	EZ	N	B	IC(A3984SLP)	IC
4	0CWE323000494	AH	DX	N	B	IC(S-93C46BD0I-D8S1G)	IC
5	0CWE323000483	AH	DX	N	B	IC(S-93C46BD0I-D8S1G)	IC
6	0CWE73543M476	AD	DJ		C	CAPACITOR(16CV47BS)	ｺﾝﾃﾞﾝｻｰ
7	0CWE74566WE03	AD	DJ	N	C	CONNECTION(B3B-XH-A-LF)	ｺﾈｸﾀｰ
8	0CWE74566WE04	AD	DJ	N	C	CONNECTION(B4B-XH-A-LF)	ｺﾈｸﾀｰ
9	0CWE7709532//	AF	DS	N	B	IC(TC7W32F)	IC
	(Unit)						
901	0CW4144K302//	CE	UF	N	E	DC CONTROLLER PWB ASSEMBLY	DC ｺﾝﾄﾛｰﾗｰ回路基板

20 前ｶﾊﾞｰﾕﾆｯﾄ (FRONT COVER UNIT)[MX-RBX1]

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4145P019／／	BK	HG	N	D	Front cover	ﾌﾛﾝﾄｶﾊﾞｰ
2	0CW040100FWBB	AC	DJ	N	C	Screw(040100FWBB)	ﾋﾞｽ
3	0CW4145P319／／	AD	DJ	N	C	Ratch spring	ﾗｯﾁﾊﾞﾈ
4	0CW4145P009／／	AE	DS	N	C	F cover ratch	ﾗｯﾁ
5	0CW4145P005／／	AE	DS	N	C	Cover sub ratch	取っ手ﾘﾝｸﾚﾊﾞｰ
6	0CW4145P029／／	AH	DX	N	C	DF open link lever(PF4145P029)	ﾕﾆｯﾄ開閉ﾘﾝｸﾚﾊﾞｰ
7	0CW020100SCH／	AA	DD		C	Pin(φ2×10)	ﾍｲｺｳﾋﾟﾝ
8	0CWNSCLP00008	AE	DJ	N	C	Clip 5(NS-CLP00008)	樹脂ｸﾘｯﾌﾟ5(取手付)
9	0CW4145P201／／	AU	FG	N	C	Ratch lever shaft	ﾌﾛﾝﾄｶﾊﾞｰ支点軸
10	0CWNSCLP00005	AE	DJ	N	C	Clip 5(NS-CLP00005)	樹脂ｸﾘｯﾌﾟ5(取手無)
11	0CW4145P006／／	AP	EQ	N	C	F cover lever	取っ手

20 前ｶﾊﾞｰﾕﾆｯﾄ (FRONT COVER UNIT)[MX-RBX1]



FCP09061

21 搬送部 No1(TRANSPORT SECTION No.1)[MX-RBX1]

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4145P308//	AF	DS	N	D	UF HDL label	上ｶﾞｲﾄﾞ JAM 処理ﾗﾍﾞﾙ
2	0CW4145P306//	AC	DJ	N	C	UF roller spring	ﾋﾟﾝﾁｺﾛ線ﾊﾞﾈ
3	0CW4076P057//	AF	DS	N	C	Pinch roller	ﾋﾟﾝﾁｺﾛ
4	0CW4145P001//	BQ	LP	N	C	UF guide	上ｶﾞｲﾄﾞ
5	0CW4145P307//	AC	DJ	N	C	UF flp cushion	上ｶﾞｲﾄﾞﾌﾗｯﾊﾟｰﾀﾞﾝﾊﾟｰ
6	0CW4145P333//	BA	FX	N	C	UF flapper	上ｶﾞｲﾄﾞﾌﾗｯﾊﾟｰ
7	0CW4145P343//	AD	DJ	N	C	UF flp mylar	ﾏｲﾗｰ
8	0CW4145P344//	AD	DJ	N	C	UF flp cushion 1	上ｶﾞｲﾄﾞﾌﾗｯﾊﾟｰﾀﾞﾝﾊﾟｰ 1
9	0CW4145P331//	AD	DJ	N	C	UF cushion F5	上ｶﾞｲﾄﾞﾀﾞﾝﾊﾟｰ 5
10	0CW4145P329//	AD	DJ	N	C	UF cushion F4	上ｶﾞｲﾄﾞﾀﾞﾝﾊﾟｰ 4
11	0CWNSBSH00002	AH	DX	N	C	Bearing	樹脂軸受
12	0CW4145P003//	AE	DJ	N	C	UF flp arm	ﾌﾗｯﾊﾟｰﾘﾝｸﾚﾊﾞｰ
13	0CWER040SKP//	AB	DD		C	E type ring 4	E ﾘﾝｸﾞ 4
14	0CW4145P327//	AR	EQ	N	C	UF cushion f2	上ｶﾞｲﾄﾞﾀﾞﾝﾊﾟｰ 2
15	0CW030100FWBB	AC	DJ	N	C	Screw(M3×10)	ﾋﾞｽ
16	0CWHW030FNS//	AC	DJ	N	C	Washer(HW-030)	平ﾜｯｼｬｰ
17	0CW2214P393//	AG	DX		C	Magnet catch 13N	ﾏｸﾞﾈｯﾄｷｬｯﾁ 13N
18	0CW4145P326//	AG	DX	N	C	UF cushion F1	上ｶﾞｲﾄﾞﾀﾞﾝﾊﾟｰ 1
19	0CW4145P345//	AD	DJ	N	C	UF flp cushion 2	上ｶﾞｲﾄﾞﾌﾗｯﾊﾟｰﾀﾞﾝﾊﾟｰ 2

21 搬送部 No1(TRANSPORT SECTION No.1)[MX-RBX1]



22 搬送部 No2(TRANSPORT SECTION No.2)[MX-RBX1]

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4145P321//	AN	EG	N	C	Heatproof prevention sheet	耐熱防止ｼｰﾄ
2	0CWNSSCR00226	AE	DJ	N	C	Screw(SCR03M040-D040015)	ﾋﾞｽ
3	0CW4145P341//	AD	DJ	N	C	Heatproof prevention sheet 2	耐熱防止ｼｰﾄ 2
4	0CW4145P109//	AS	EQ	N	C	DCN guide	入口後ｺﾛﾕﾆｯﾄｶﾞｲﾄﾞ
5	0CW4145P309//	AG	DX	N	C	DCN up mylar	ﾏｲﾗｰ
6	0CW4145P107//	AH	DX	N	C	DCN f guide arm	入口後ｺﾛﾕﾆｯﾄ前ﾌﾞﾗｹｯﾄ
7	0CWNSBRG00110	AU	EZ	N	C	Bearing(NS-BRG00110)	ﾍﾞｱﾘﾝｸﾞ
8	0CWER040SKP//	AB	DD		C	E type ring 4	Eﾘﾝｸﾞ 4
10	0CW4145P202//	AV	FG	N	C	DCN shaft	入口後ｺﾛ
11	0CW4145P108//	AH	DX	N	C	DCN R guide arm	入口後ｺﾛﾕﾆｯﾄ後ﾌﾞﾗｹｯﾄ
12	0CWNSSCR00017	AD	DJ	N	C	Screw(NS-SCR00017)	ﾋﾞｽ
13	0CW040080FWWS	AC	DJ	N	C	Screw(SCR040080FWWS)	ﾋﾞｽ
14	0CW4145P101//	AN	EG	N	C	Positioning bracket	位置決めﾌﾞﾗｹｯﾄ
15	0CWE450000384	AB	DD		C	Edge suddle(EDS-2)	ｴｯｼﾞｻﾄﾞﾙ
16	0CW4145K532//	BA	FX	N	C	Harness-RELAY-UNIT(PF4145K532)	ﾄﾞﾛﾜﾊｰﾈｽ
17	0CW030080FWBi	AC	DJ	N	C	Screw(SCR-030-080)	ﾋﾞｽ
18	0CW4145P312//	AG	DX	N	C	Earth spring(150-120-5000)	ﾕﾆｯﾄｱｰｽﾊﾞﾈ
19	0CW4145P205//	AR	EQ	N	C	Positioning shaft	位置決め軸
21	0CW4145P104//	AK	DX	N	C	UF hinge bracket	上ｶﾞｲﾄﾞ支点ﾌﾞﾗｹｯﾄ
22	0CW030060FWWS	AC	DJ	N	C	Screw(SCR03M060-WS-W)	ﾋﾞｽ
23	0CW4145P015//	AF	DS	N	C	DCN up lever	入口後ｺﾛﾕﾆｯﾄ解除ﾚﾊﾞｰ
24	0CWNSCLP00005	AE	DJ	N	C	Clip 5(NS-CLP00005)	樹脂ｸﾘｯﾌﾟ 5(取手無)
26	0CWHW030FNS//	AC	DJ	N	C	Washer(HW-030)	平ﾜｯｼｬｰ
27	0CW4145P004//	AE	DS	N	C	UF solenoid lever	ｿﾚﾉｲﾄﾞﾘﾝｸﾚﾊﾞｰ
28	0CW4145P305//	AD	DJ	N	C	Solenoid link spring(40-216-854)	ｿﾚﾉｲﾄﾞﾘﾝｸﾊﾞﾈ
29	0CW4145K552//	BE	GN	N	B	Solenoid(TDS-12E-81A)	ﾌﾗｯﾊﾟｰｿﾚﾉｲﾄﾞ
30	0CW4145P347//	AE	DJ		C	Cushion-SOL-P(PF4145P347)	ｿﾚﾉｲﾄﾞﾀﾞﾝﾊﾟｰ
31	0CW4145P103//	AF	DS	N	C	Solenoid bracket	ｿﾚﾉｲﾄﾞﾌﾞﾗｹｯﾄ
32	0CW030050FWWS	AC	DJ	N	C	Screw(030050FWWS)	ﾋﾞｽ
33	0CW4145P324//	AF	DS	N	C	Stopper band	ｽﾄｯﾊﾟｰﾊﾞﾝﾄﾞ
34	0CW030100FWBB	AC	DJ	N	C	Screw(M3×10)	ﾋﾞｽ
501	0CW4145K018//	AG	DS	N	E	Hinge beracket	入口後ｺﾛﾕﾆｯﾄ支点ｶｼﾒﾌﾞﾗｹｯﾄ

22 搬送部 No2(TRANSPORT SECTION No.2)[MX-RBX1]



23 搬送部 No3(TRANSPORT SECTION No.3)[MX-RBX1]

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4145P013//	BS	MW	N	D	DF guide	下ｶﾞｲﾄﾞ
2	0CW4145P315//	AC	DJ	N	C	DCN down mylar 1	ﾏｲﾗｰ
3	0CW4145P336//	AC	DJ	N	C	DF cushion 5-7	上ｶﾞｲﾄﾞﾌﾗｯﾊﾟｰﾀﾞﾝﾊﾟｰ
4	0CW4145P028//	AE	DS	N	C	Harness holder	ﾊｰﾈｽ押さえ
5	0CW4145P342//	AD	DJ	N	C	DF solenoid cushion	ｿﾚﾉｲﾄﾞﾀﾞﾝﾊﾟｰ
6	0CW030100FWBB	AC	DJ	N	C	Screw(M3×10)	ﾋﾞｽ
7	0CW4145K551//	BD	GN	N	B	Fan(3110RL-05W-B39)	ﾌｧﾝﾓｰﾀｰ
8	0CWNSSCR00087	AE	DS	N	C	Screw(NS-SCR00087)	ﾋﾞｽ
9	0CW4145P030//	AH	DX	N	C	DF sensor lever	紙ﾊﾟｽｾﾝｻｰﾚﾊﾞｰ
10	0CW4145P338//	AD	DJ	N	C	Sensor spring(30-214-34)	紙ﾊﾟｽｾﾝｻｰﾊﾞﾈ
11	0CW4145K021//	AZ	FQ	N	C	Rear frame bracket	ﾘｱ側板ｶｼﾒﾌﾞﾗｹｯﾄ
12	0CWNSBRG00110	AU	EZ	N	C	Bearing(NS-BRG00110)	ﾍﾞｱﾘﾝｸﾞ
13	0CWER040SKP//	AB	DD		C	E type ring 4	Eﾘﾝｸﾞ 4
14	0CW4145P110//	AG	DS	N	C	Pas sensor bracket	紙ﾊﾟｽｾﾝｻｰﾌﾞﾗｹｯﾄ
15	0CWE314000784	AP	EQ	N	B	Sensor(E314000784)(GP1S73P2J00F)	ｾﾝｻｰ
16	0CWNSSCR00017	AD	DJ	N	C	Screw	ﾋﾞｽ
17	0CW4145P311//	AS	EZ	N	C	Motor out joint	ﾜﾝｳｪｲｼﾞｮｲﾝﾄ
18	0CW4145P026//	AE	DS	N	C	Pulley	ﾌﾟｰﾘｰ
19	0CWNSBLT00338	AS	EQ	N	B	Belt(NS-BLT00338)	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
20	0CWER050SKP//	AA	DD		C	E type ring 5	Eﾘﾝｸﾞ 5
21	0CW4145P035//	AE	DJ	N	C	Pulley(S3M-16)	ﾌﾟｰﾘｰ
22	0CW2268P076//	AD	DJ		C	Flange	樹脂ﾌﾗﾝｼﾞ
23	0CWNSBLT00339	AR	EQ	N	B	Belt(S3M068040)	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
24	0CW4145P010//	AF	DS	N	C	Pulley(S3M-16-25)	ﾌﾟｰﾘｰ
25	0CWNSBLT00333	AS	EQ	N	B	Belt(S3M054040)	ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ
26	0CW040100FWBB	AC	DJ	N	C	Screw(040100FWBB)	ﾋﾞｽ
27	0CW030060FWWS	AC	DJ	N	C	Screw(030060FWWS)	ﾋﾞｽ
28	0CW4145K550//	BL	HL	N	B	Drive motor(PF4145K550)	駆動ﾓｰﾀｰ
29	0CW020100SCH/	AA	DD		C	Pin(φ2×10)	ﾍｲｺｳﾋﾟﾝ
30	0CW4145P300//	AY	FQ	N	C	DF in delivery roller	入口搬送ﾛｰﾗ
31	0CW4145P303//	AZ	FX	N	C	DF dcn delivery roller	排紙搬送ﾛｰﾗ
32	0CW4145P301//	BA	FX	N	C	DF out delivery roller 1	入口後搬送ﾛｰﾗ 1
33	0CW4145P302//	AY	FQ	N	C	DF out delivery roller 2	排紙前搬送ﾛｰﾗ 2
34	0CW4145P025//	BQ	LP	N	D	Bottom cover	底ｶﾊﾞｰ
35	0CW4145K020//	AZ	FX	N	C	Front frame bracket	ﾌﾛﾝﾄ側板ｶｼﾒﾌﾞﾗｹｯﾄ
36	0CWWT25035000	AD	DJ		C	Edge saddle(EDS-0607M)	ｴｯｼﾞｻﾄﾞﾙ
37	0CWPW060025//	AA	DJ		C	Poliyslider	ﾎﾟﾘｽﾗｲﾀﾞｰ
38	0CW4145P317//	AD	DJ	N	C	Spring(73-100-6000)	ﾛｰﾗｶﾞﾀ止めﾊﾞﾈ
39	0CWE450001148	AE	DS	N	C	HARENSS CLAMP(RLMC-05T V0)	ﾊｰﾈｽｸﾗﾝﾌﾟ
40	0CWE450001128	AC	DJ		C	Wire band(RSG-100)	ﾜｲﾔｰﾊﾞﾝﾄﾞ

23 搬送部 No3(TRANSPORT SECTION No.3)[MX-RBX1]



24 排紙ﾄﾚｲ & ﾚｰﾙ部 (DELIVERY PAPER TARY & RAIL SECTION)[MX-RBX1]

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW040080FWBP	AC	DJ	N	C	Screw(SCR-040-080WBP)	ﾋﾞｽ
2	0CW4145P012//	BH	GX	N	D	Left cover	左ｶﾊﾞｰ
4	0CW4145P017//	AG	DX	N	C	Lock hfs holder	ﾌｨﾆｯｼｬｰﾗｯﾁ受け
6	0CW4145P032//	AE	DS	N	C	UF holder	上ｶﾞｲﾄﾞ押さえ
7	0CW4145K010//	BH	GX	N	C	Left frame bracket	左ﾚｰﾙｶｼﾒﾌﾞﾗｹｯﾄ
9	0CW4145P502//	AR	EQ	N	C	Screw(JFS-2.6S-B1WM)	IF ｺﾈｸﾀｰ固定ﾈｼﾞ
10	0CW4145P018//	BL	HG	N	C	Reverse tray	反転ﾄﾚｲ
11	0CWNSCLP00008	AE	DJ	N	C	Clip 8(050140W)	樹脂ｸﾘｯﾌﾟ 8
12	0CWNSCLP00005	AE	DJ	N	C	Clip 5(050060W)	樹脂ｸﾘｯﾌﾟ 5
13	0CWNSBSH00002	AH	DX	N	C	Bearing	樹脂軸受
15	0CW4145P024//	AE	DS	N	C	Reverse flp link lever	反転ﾌﾗｯﾊﾟｰﾘﾝｸﾚﾊﾞｰ
16	0CW4145P124//	AG	DX	N	C	Reverse tray bracket	反転ﾄﾚｲ補強ﾌﾞﾗｹｯﾄ
17	0CW030100FWBB	AC	DJ	N	C	Screw(030100FWBB)	ﾋﾞｽ
18	0CW4145P351//	AG	DX	N	C	Screw(SCR-040-060-D-CO1N-1)	反転ﾄﾚｲ固定ﾈｼﾞ
19	0CW4145P334//	BA	FX	N	C	Reverse flapper	反転ﾌﾗｯﾊﾟｰ
20	0CW4145P346//	AD	DJ	N	C	Reverse tray cushion	反転ﾄﾚｲﾀﾞﾝﾊﾟｰ
21	0CWNSSCR00017	AD	DJ	N	C	Screw(NS-SCR00017)	ﾋﾞｽ
22	0CW4145P121//	AN	EG	N	C	Pntrance guide	入口ｶﾞｲﾄﾞ
23	0CW4145P033//	AG	DS	N	C	Sensor lever	本体排紙ｾﾝｻｰﾚﾊﾞｰ
24	0CW4145P105//	BF	GN	N	C	Right rail	右ﾚｰﾙ
25	0CW4141P082//	AF	DS	N	C	Frame holder	本体ｼﾌﾀｰ押さえ
27	0CW4145P034//	AR	EQ	N	C	Right rail stopper	右ﾚｰﾙたわみ防止
28	0CW4145P016//	AE	DJ	N	C	Rail collar	ﾚｰﾙ用ｺﾛ
29	0CWER050SKP//	AA	DD		C	E type ring 5	E ﾘﾝｸﾞ 5
31	0CW4145P123//	AG	DX	N	C	Sensor bracket	ﾕﾆｯﾄ開閉ｾﾝｻｰﾌﾞﾗｹｯﾄ
32	0CWE314000784	AP	EQ	N	B	Sensor(GP1S73P2J00F)	ｾﾝｻｰ
33	0CW4111P349//	AD	DJ	N	C	Screw	ﾋﾞｽ
34	0CW4145P116//	AR	EQ	N	C	Drawer bracket	ﾄﾞﾛﾜﾌﾞﾗｹｯﾄ
35	0CWE450001139	AC	DJ		C	Clamp(E450001139)	ｸﾗﾝﾌﾟ
36	0CWNSSCR00225	AC	DJ	N	C	Screw(SCR03M030-D040020)	ﾋﾞｽ
37	0CW4145P313//	AE	DJ	N	C	Drawer spring	ﾄﾞﾛﾜﾊﾞﾈ
38	0CWE75317BK22	BB	GD	N	C	Drawer connector(5-292178-1)	ﾄﾞﾛﾜｺﾈｸﾀ
39	0CW4145P112//	AX	FG	N	C	Left rail bracket	左ﾚｰﾙﾌﾞﾗｹｯﾄ
40	0CW4145P027//	AG	DX	N	C	Stopper	ﾕﾆｯﾄｽﾄｯﾊﾟｰ
41	0CW4145P031//	AE	DS	N	C	Open sensor lever	ﾕﾆｯﾄ開閉ｾﾝｻｰﾚﾊﾞｰ
42	0CW4145P330//	AE	DJ	N	C	Stopper spring	ﾕﾆｯﾄｽﾄｯﾊﾟｰﾊﾞﾈ
43	0CW4141P368//	AF	DS	N	C	Mylar	ﾏｲﾗｰ
44	0CWE450001128	AC	DJ		C	Wire band(RSG-100)	ﾜｲﾔｰﾊﾞﾝﾄﾞ
45	0CWE450001297	AH	DX	N	C	CLIP(RES-6)	ｸﾘｯﾌﾟ
46	0CW4145K510//	BL	HL	N	E	Relay1 PWB unit(PF4145K510)	中継基板組
47	0CW4145K534//	AN	EG	N	C	Harness-OPEN-SEN(PF4145K534)	ﾊｰﾈｽ
48	0CW4145K533//	AK	DX	N	C	Harness-OPEN(PF4145K533)	ﾊｰﾈｽ
49	0CW4145K531//	AS	EQ	N	C	Harness-RELAY1(PF4145K531)	ﾊｰﾈｽ
50	0CW4145K535//	AR	EQ	N	C	Harness-RELAY2(PF4145K535)	ﾊｰﾈｽ
51	0CW4145K532//	BA	FX	N	C	Harness-RELAY-UNIT(PF4145K532)	ﾄﾞﾛﾜﾊｰﾈｽ
52	0CW4145P336//	AC	DJ	N	C	DF cushion 5-7	上ｶﾞｲﾄﾞﾌﾗｯﾊﾟｰﾀﾞﾝﾊﾟｰ
53	0CWE450000384	AB	DD		C	Edge saddle(EDS-2)	ｴｯｼﾞｻﾄﾞﾙ
54	0CWE74561WE03	AE	DS	N	C	Connector(292254-3)	中継ｺﾈｸﾀ

24 排紙ﾄﾚｲ & ﾚｰﾙ部 (DELIVERY PAPER TARY & RAIL SECTION)[MX-RBX1]



25 梱包 & 付属品 (PACKING MATERIAL & ACCESSORIES)[MX-RBX1]

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION	
		Ex.	Ja.				
1	0CW4145P401／／	BH	GX	N	D	Packing case(for JAPAN)	個装ｹｰｽ
	0CW4145P407／／	BF	GN	N	D	Packing case(except JAPAN)	個装ｹｰｽ
3	0CW2216P524／／	AE	DS		D	Vinyl bag(470×800mm)	ﾋﾞﾆｰﾙﾌﾞｸﾛ A (ｱﾅｱｷ)
5	0CW2148P093／／	AG	DX		D	Vinyl bag(900×800mm)	ﾋﾞﾆｰﾙﾌﾞｸﾛ ｱﾅｱｷ
9	0CW616371／／／／	AA	DJ		D	Vinyl bag C(80×120mm)	ﾋﾞﾆｰﾙﾌﾞｸﾛ C
11	0CW4134P420／／	AF	DS		D	Operation manual	設置手順書
13	0CW040080FWBP	AC	DJ	N	C	Screw(040080FWBP)	ﾋﾞｽ
14	0CW4145P351／／	AG	DX	N	C	Screw	反転ﾄﾚｲ固定ﾈｼﾞ
15	0CW4145P034／／	AR	EQ	N	C	Right rail stopper	右ﾚｰﾙたわみ防止
16	0CW4145P033／／	AG	DS	N	C	Sensor lever	本体排紙ｾﾝｻｰﾚﾊﾞｰ

25 梱包 & 付属品 (PACKING MATERIAL & ACCESSORIES)[MX-RBX1]



FCP09066

■ 索引 (Index)

PARTS CODE	NO.	PRICE R. Ex.	PRICE R. Ja.	NEW	P/R	
【0】						
0CW020100SCH/	20- 7	AA	DD		C	
〃	23- 29	AA	DD		C	
0CW030050FWWS	22- 32	AC	DJ	N	C	
0CW030060FWWS	22- 22	AC	DJ	N	C	
〃	23- 27	AC	DJ	N	C	
0CW030060FZBi	13- 88	AA	DD		C	
0CW030080FDBB	5- 29	AB	DJ	N	C	
0CW030080FWBi	22- 17	AC	DJ	N	C	
0CW030100FWBB	21- 15	AC	DJ	N	C	
〃	22- 34	AC	DJ	N	C	
〃	23- 6	AC	DJ	N	C	
〃	24- 17	AC	DJ	N	C	
0CW040060FNBi	2- 80	AA	DD		C	
0CW040060FZTW	18- 7	AC	DJ		C	
0CW040080FWBP	24- 1	AC	DJ	N	C	
〃	25- 13	AC	DJ	N	C	
0CW040080FWWS	15- 54	AC	DJ	N	C	
〃	22- 13	AC	DJ	N	C	
0CW040080FZWS	1-601	AA	DD		C	
0CW040100FNBi	1- 58	AA	DD		C	
0CW040100FWBB	20- 2	AC	DJ	N	C	
〃	23- 26	AC	DJ	N	C	
0CW040100FWWS	2- 72	AC	DJ	N	C	
0CW040120FNBB	1- 57	AB	DJ		C	
〃	2- 79	AB	DJ		C	
0CW040180NBP/	17- 21	AC	DJ	N	C	
0CW0412FNBiT2	2- 74	AC	DJ	N	C	
0CW1020K363B/	6- 16	AX	FG		E	
0CW1020K365B/	6- 17	AX	FG		E	
0CW1020K367//	5- 11	AP	EQ	N	E	
0CW1020K369//	5- 12	AP	EQ	N	E	
0CW1020K374//	18- 6	AN	EG		D	
0CW1020K375//	18- 4	AH	DX		D	
0CW1020K435//	18- 2	AY	FQ		D	
0CW1020P280A/	5- 54	AH	DX		C	
0CW1020P537A/	5- 50	BS	MJ		B	
0CW1020P711B/	18-100	AK	DX		D	
0CW1020P827//	18- 5	AQ	EQ		D	
0CW1020P832//	18- 3	AF	DS		D	
0CW1033K300//	6- 14	BD	GN	N	B	
0CW2111P021//	18- 1	AC	DJ		D	
0CW2148P093//	25- 5	AG	DX		D	
0CW2158P380//	17- 9	AE	DJ		D	
0CW2214P358//	17- 14	AB	DJ		D	
0CW2214P393//	21- 17	AG	DX		C	
0CW2216P524//	17- 4	AE	DS		D	
〃	25- 3	AE	DS		D	
0CW2268P076//	23- 22	AD	DJ		C	
0CW3090P360//	2- 75	AD	DJ		C	
0CW32300048//	19- 1	AH	DX	N	B	
0CW4048P076//	2- 82	AD	DJ	N	C	
0CW4048P300//	4- 39	AC	DJ		C	
0CW4060P027//	10- 9	AB	DJ	N	C	
〃	4- 16	AB	DJ	N	C	
〃	9- 21	AB	DJ	N	C	
0CW4076P057//	21- 3	AF	DS	N	C	
0CW4088P220//	17- 8	AQ	EQ		D	
0CW4099K310//	16- 37	AM	EG	N	E	
0CW4099K312//	16- 38	AP	EQ	N	E	
0CW4099P903//	17- 11	AL	EB		D	
0CW4099P911//	17- 28	AC	DJ		D	
0CW4099P912//	17- 27	AD	DJ		D	
0CW4099P913//	17- 23	AC	DJ		D	
0CW4099Q031//	2- 71	AD	DJ	N	C	
0CW4109P207//	3- 68	AD	DJ	N	C	
0CW4109P231//	11- 6	AD	DJ		C	
0CW4109P232//	11- 7	AD	DJ		C	
0CW4109P247//	3- 1	AY	FQ	N	C	
0CW4109P248//	3- 13	AV	FG	N	C	
0CW4109P427//	3- 67	AC	DJ	N	C	
0CW4109P449//	13- 73	AD	DJ		C	
0CW4110P026//	2- 86	AM	EG	N	C	
0CW4110P362//	11- 64	AD	DJ		C	
0CW4110Q165//	17- 13	AL	EB	N	D	
0CW4111P349//	24- 33	AD	DJ	N	C	
0CW4113K034//	12- 76	AU	FG		C	
0CW4113K158A/	13- 87	AS	EQ		C	
0CW4113P027A/	2- 78	AK	DX		C	

PARTS CODE	NO.	PRICE R. Ex.	PRICE R. Ja.	NEW	P/R	
0CW4113P243//	9- 9	AE	DS		C	
0CW4113P352//	11- 49	AG	DX		C	
0CW4113P643B/	11- 35	AR	EQ		C	
0CW4114P048B/	10- 23	AU	EZ		C	
0CW4114P352//	11- 33	AH	DX	N	C	
0CW4114P401//	11- 70	AE	DJ		C	
0CW4114P813//	11- 24	AF	DS		C	
0CW4116P405B/	4- 38	BA	FX		C	
0CW4116P492//	9- 17	AL	EB		C	
0CW4116P759//	11- 38	AN	EG		C	
0CW4134K328//	4- 37	AF	DS		C	
0CW4134P042//	1- 51	AN	EQ		D	
0CW4134P401//	11- 70	AE	DS		C	
0CW4134P420//	17- 15	AF	DS		D	
〃	25- 11	AF	DS		D	
0CW4135K550//	7- 6	BD	GN		B	
0CW4135P439//	12- 81	AF	DJ		C	
0CW4135Q401//	15- 58	AE	DJ	N	C	
0CW4139P139//	11- 57	AR	FG		C	
0CW4141P082//	24- 25	AF	DS	N	C	
0CW4141P368//	24- 43	AF	DS	N	C	
0CW4144K100//	1- 10	BK	HC	N	C	
0CW4144K146//	5- 26	AW	FG	N	E	
0CW4144K302//	19-901	CE	UF	N	E	
〃	4- 46	CE	UF	N	E	
0CW4144K501//	2- 57	BC	GJ	N	C	
0CW4144K502//	2- 5	BA	FX	N	C	
0CW4144K600//	17- 2	BP	LP	N	D	
0CW4144P002//	1- 52	AP	EQ	N	C	
0CW4144P003//	1- 53	AL	EB	N	C	
0CW4144P004//	1- 4	BA	FX	N	C	
0CW4144P005//	1- 38	AU	FG	N	C	
0CW4144P007//	2- 70	AG	DX	N	C	
0CW4144P016//	3- 48	AG	DX	N	C	
0CW4144P053//	10- 69	AP	EQ	N	C	
0CW4144P100//	2- 69	AZ	FQ	N	C	
0CW4144P200//	2- 22	BF	GN	N	D	
0CW4144P201//	2- 23	BE	GN	N	D	
0CW4144P202//	2- 2	BK	HG	N	D	
0CW4144P203//	2- 17	BB	GD	N	D	
0CW4144P204//	2- 61	BC	GD	N	D	
0CW4144P205//	2- 16	AK	EB	N	D	
0CW4144P206//	2- 7	BA	FX	N	D	
0CW4144P207//	2- 62	AR	EQ	N	C	
0CW4144P208//	2- 63	AN	EQ	N	D	
0CW4144P209//	2- 65	AP	EQ	N	D	
0CW4144P210//	2- 4	AL	EB	N	D	
0CW4144P211//	2- 64	AH	DX	N	C	
0CW4144P212//	3- 15	AG	DX	N	C	
0CW4144P213//	2- 33	BC	GJ	N	C	
0CW4144P214//	2- 73	AP	EQ	N	D	
0CW4144P215//	4- 24	AL	EB	N	C	
0CW4144P216//	2- 67	AF	DS	N	C	
0CW4144P217//	2- 56	AE	DS	N	C	
0CW4144P220//	2- 76	AH	DX	N	D	
0CW4144P222//	2- 77	AH	DX	N	D	
0CW4144P235//	2- 11	BA	FX	N	D	
0CW4144P245//	5- 27	AS	EZ	N	C	
0CW4144P250//	1- 46	BD	GN	N	D	
0CW4144P251//	1- 24	BC	GJ	N	D	
0CW4144P252//	1- 56	AM	EG	N	C	
0CW4144P253//	1- 14	BC	GD	N	D	
0CW4144P254//	1- 47	BF	GN	N	D	
0CW4144P277//	10- 38	AG	DX	N	D	
0CW4144P284//	10- 41	AG	DX	N	D	
0CW4144P289//	10- 35	AR	EQ	N	C	
0CW4144P290//	10- 32	AR	EQ	N	C	
0CW4144P303//	10- 8	AL	EB	N	D	
0CW4144P314//	4- 23	AD	DJ	N	C	
0CW4144P361//	17- 20	AF	DS	N	D	
0CW4144P362//	17- 19	AF	DS	N	D	
0CW4144P363//	17- 18	AF	DS	N	D	
0CW4144P364//	17- 17	AF	DS	N	D	
0CW4144P381//	2- 34	AK	EB	N	C	
0CW4144P391//	2- 10	BA	FX	N	C	
0CW4144P393//	2- 30	AS	EQ	N	D	
0CW4144P394//	2- 31	AX	FG	N	D	
0CW4144P400//	3- 9	AD	DJ	N	C	
0CW4144P401//	2- 68	AH	DX	N	C	
0CW4144P402//	2- 85	AE	DS	N	C	
0CW4144P408//	10- 70	AF	DS	N	C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CW4144P433//	2- 40	AY	FQ	N	D	
0CW4144P445//	5- 28	AH	DX	N	C	
0CW4144P469//	2- 84	BC	GJ	N	B	
0CW4144P705//	4- 1	AL	EB	N	D	
0CW4144P726//	2- 3	AY	FQ	N	D	
0CW4144P727//	2- 26	BE	GN	N	C	
0CW4144P728//	2- 27	BA	FX	N	C	
0CW4144P751//	4- 27	AG	DX	N	C	
0CW4144P763//	2- 9	AT	EZ	N	C	
0CW4144P900//	17- 12	BQ	LP	N	D	
0CW4144P901//	17- 1	BG	GT	N	D	
0CW4144P902//	17- 1	BG	GT	N	D	
0CW4144P908//	17- 3	AL	EB	N	D	
0CW4144P909//	17- 7	AE	DJ	N	D	
0CW4144P910//	17- 26	AQ	EQ	N	D	
0CW4144P911//	17- 24	AE	DS	N	D	
0CW4144P912//	17- 25	AE	DJ	N	D	
0CW4144P950//	2- 83	AC	DJ	N	C	
0CW4145K010//	24- 7	BH	GX	N	C	
0CW4145K018//	22-501	AG	DS	N	E	
0CW4145K020//	23- 35	AZ	FX	N	C	
0CW4145K021//	23- 11	AZ	FQ	N	C	
0CW4145K510//	24- 46	BL	HL	N	E	
0CW4145K531//	24- 49	AS	EQ	N	C	
0CW4145K532//	22- 16	BA	FX	N	C	
〃	24- 51	BA	FX	N	C	
0CW4145K533//	24- 48	AK	DX	N	C	
0CW4145K534//	24- 47	AN	EG	N	C	
0CW4145K535//	24- 50	AR	EQ	N	C	
0CW4145K550//	23- 28	BL	HL	N	B	
0CW4145K551//	23- 7	BD	GN	N	B	
0CW4145K552//	22- 29	BE	GN	N	B	
0CW4145P001//	21- 4	BQ	LP	N	C	
0CW4145P003//	21- 12	AE	DJ	N	C	
0CW4145P004//	22- 27	AE	DS	N	C	
0CW4145P005//	20- 5	AE	DS	N	C	
0CW4145P006//	20- 11	AP	EQ	N	C	
0CW4145P009//	20- 4	AE	DS	N	C	
0CW4145P010//	23- 24	AF	DS	N	C	
0CW4145P012//	24- 2	BH	GX	N	D	
0CW4145P013//	23- 1	BS	MW	N	D	
0CW4145P015//	22- 23	AF	DS	N	C	
0CW4145P016//	24- 28	AE	DJ	N	C	
0CW4145P017//	24- 4	AG	DX	N	C	
0CW4145P018//	24- 10	BL	HG	N	C	
0CW4145P019//	20- 1	BK	HG	N	D	
0CW4145P024//	24- 15	AE	DS	N	C	
0CW4145P025//	23- 34	BQ	LP	N	D	
0CW4145P026//	23- 18	AE	DS	N	C	
0CW4145P027//	24- 40	AG	DX	N	C	
0CW4145P028//	23- 4	AE	DS	N	C	
0CW4145P029//	20- 6	AH	DX	N	C	
0CW4145P030//	23- 9	AH	DX	N	C	
0CW4145P031//	24- 41	AE	DS	N	C	
0CW4145P032//	24- 6	AE	DS	N	C	
0CW4145P033//	24- 23	AG	DS	N	C	
〃	25- 16	AG	DS	N	C	
0CW4145P034//	24- 27	AR	EQ	N	C	
〃	25- 15	AR	EQ	N	C	
0CW4145P035//	23- 21	AE	DJ	N	C	
0CW4145P101//	22- 14	AN	EG	N	C	
0CW4145P103//	22- 31	AF	DS	N	C	
0CW4145P104//	22- 21	AK	DX	N	C	
0CW4145P105//	24- 24	BF	GN	N	C	
0CW4145P107//	22- 6	AH	DX	N	C	
0CW4145P108//	22- 11	AH	DX	N	C	
0CW4145P109//	22- 4	AS	EQ	N	C	
0CW4145P110//	23- 14	AG	DS	N	C	
0CW4145P112//	24- 39	AX	FG	N	C	
0CW4145P116//	24- 34	AR	EQ	N	C	
0CW4145P121//	24- 22	AN	EG	N	C	
0CW4145P123//	24- 31	AG	DX	N	C	
0CW4145P124//	24- 16	AG	DX	N	C	
0CW4145P201//	20- 9	AU	FG	N	C	
0CW4145P202//	22- 10	AV	FG	N	C	
0CW4145P205//	22- 19	AR	EQ	N	C	
0CW4145P300//	23- 30	AY	FQ	N	C	
0CW4145P301//	23- 32	BA	FX	N	C	
0CW4145P302//	23- 33	AY	FQ	N	C	
0CW4145P303//	23- 31	AZ	FX	N	C	
0CW4145P305//	22- 28	AD	DJ	N	C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CW4145P306//	21- 2	AC	DJ	N	C	
0CW4145P307//	21- 5	AC	DJ	N	C	
0CW4145P308//	21- 1	AF	DS	N	D	
0CW4145P309//	22- 5	AG	DX	N	C	
0CW4145P311//	23- 17	AS	EZ	N	C	
0CW4145P312//	22- 18	AG	DX	N	C	
0CW4145P313//	24- 37	AE	DJ	N	C	
0CW4145P315//	23- 2	AC	DJ	N	C	
0CW4145P317//	23- 38	AD	DJ	N	C	
0CW4145P319//	20- 3	AD	DJ	N	C	
0CW4145P321//	22- 1	AN	EG	N	C	
0CW4145P324//	22- 33	AF	DS	N	C	
0CW4145P326//	21- 18	AG	DX	N	C	
0CW4145P327//	21- 14	AR	EQ	N	C	
0CW4145P329//	21- 10	AD	DJ	N	C	
0CW4145P330//	24- 42	AE	DJ	N	C	
0CW4145P331//	21- 9	AD	DJ	N	C	
0CW4145P333//	21- 6	BA	FX	N	C	
0CW4145P334//	24- 19	BA	FX	N	C	
0CW4145P336//	23- 3	AC	DJ	N	C	
〃	24- 52	AC	DJ	N	C	
0CW4145P338//	23- 10	AD	DJ	N	C	
0CW4145P341//	22- 3	AD	DJ	N	C	
0CW4145P342//	23- 5	AD	DJ	N	C	
0CW4145P343//	21- 7	AD	DJ	N	C	
0CW4145P344//	21- 8	AD	DJ	N	C	
0CW4145P345//	21- 19	AD	DJ	N	C	
0CW4145P346//	24- 20	AD	DJ	N	C	
0CW4145P347//	22- 30	AE	DJ		C	
0CW4145P351//	24- 18	AG	DX	N	C	
〃	25- 14	AG	DX	N	C	
0CW4145P401//	25- 1	BH	GX	N	D	
0CW4145P407//	25- 1	BF	GN	N	D	
0CW4145P502//	24- 9	AR	EQ	N	C	
0CW4A12609000	1- 44	AC	DJ		C	
0CW4A17172010	4- 10	AN	EQ		C	
0CW4A17173000	7- 16	AD	DJ		C	
0CW4A17175000	14- 74	AF	DS		C	
0CW4A17176000	14- 75	AF	DS		C	
0CW4A17177000	13- 1	AG	DS		C	
0CW4A17178000	13- 2	AG	DS		C	
0CW4A17179000	13- 85	AV	FG		C	
0CW4A17180000	13- 84	AN	EG		C	
0CW4A17181000	13- 77	AG	DX		C	
0CW4A17184000	9- 20	AN	EG		C	
0CW4A17186010	14- 64	AL	EB		C	
0CW4A17187000	14- 61	AK	EB		C	
0CW4A17188000	13- 86	AF	DS		C	
0CW4A17191000	10- 52	AF	DS		C	
0CW4A17192000	11- 58	AE	DS		C	
0CW4A17193000	10- 56	AG	DS		C	
0CW4A17194000	11- 31	AR	EQ		C	
0CW4A17195000	2- 20	AF	DS		C	
0CW4A17196000	10- 60	AH	DX		C	
0CW4A17198000	8- 30	AQ	EQ		C	
0CW4A17199000	8- 26	AE	DJ		C	
0CW4A17202000	11- 62	AK	DX		C	
0CW4A17203010	13- 80	AL	EB		C	
0CW4A17204000	14- 69	AM	EG		C	
0CW4A17207000	14- 67	AR	EQ		C	
0CW4A17209000	10- 31	AC	DJ		C	
0CW4A17212000	10- 42	AE	DS		C	
0CW4A17217000	3- 57	AV	FG		C	
0CW4A17227000	12- 79	AT	EZ		C	
0CW4A17228010	13- 71	AC	DJ		C	
0CW4A17229000	8- 28	AL	EB		C	
0CW4A17231000	8- 29	AL	EB		C	
0CW4A17234000	11- 60	AR	EQ		C	
0CW4A17236000	10- 54	AS	EQ		C	
0CW4A17237000	11- 63	AT	EZ		C	
0CW4A17238000	11- 67	AR	EQ		C	
0CW4A17239000	10- 50	AK	DX		C	
0CW4A17240000	9- 7	AM	EG		C	
0CW4A17242000	13- 78	AU	FG		C	
0CW4A17253000	3- 59	AS	EZ		C	
0CW4A17254000	14- 72	AX	FQ		C	
0CW4A17255000	14- 73	AY	FQ		C	
0CW4A17256000	12- 73	AN	EG		C	
0CW4A17259000	3- 3	AD	DJ		C	
0CW4A17260000	7- 1	AF	DS		C	
0CW4A17261000	7- 2	AG	DS		C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CW4A17262000	7- 3	AE	DS		C	
0CW4A17263000	7- 4	AE	DS		C	
0CW4A17264000	7- 13	AE	DJ		C	
0CW4A17265000	3- 29	AC	DJ		C	
0CW4A17266000	10- 62	AE	DS		C	
0CW4A17270000	2- 32	AG	DS		C	
0CW4A17271000	11- 10	AP	EQ		C	
0CW4A17272000	11- 11	AN	EQ		C	
0CW4A17273000	10- 15	AD	DJ		C	
0CW4A17274000	11- 12	AD	DJ		C	
0CW4A17275000	10- 27	AD	DJ		C	
0CW4A17276000	11- 13	AC	DJ		C	
0CW4A17278000	11- 1	AC	DJ		C	
0CW4A17279000	11- 14	AD	DJ		C	
0CW4A17280000	11- 15	AD	DJ		C	
0CW4A17281000	11- 2	AD	DJ		C	
0CW4A17282000	11- 45	AC	DJ		C	
0CW4A17283000	11- 44	AC	DJ		C	
0CW4A17284000	2- 41	AD	DJ		C	
0CW4A17285000	11- 50	AE	DS		C	
0CW4A17286000	11- 46	AE	DS		C	
0CW4A17288000	3- 24	AD	DJ		C	
0CW4A17289000	9- 8	AF	DS		C	
0CW4A17290000	14- 3	AE	DS		C	
0CW4A17291000	2- 12	AE	DS		C	
0CW4A17295000	13- 4	AD	DJ		C	
0CW4A17296000	13- 5	AD	DJ		C	
0CW4A17297000	13- 68	AC	DJ		C	
0CW4A17298000	13- 74	AF	DS		C	
0CW4A17299000	12- 6	AG	DX		C	
0CW4A17300000	8- 16	AD	DJ		C	
0CW4A17301000	8- 1	AE	DS		C	
0CW4A17302000	8- 2	AQ	EQ		C	
0CW4A17303000	8- 3	AK	DX		C	
0CW4A17304000	8- 4	AL	EB		C	
0CW4A17305000	8- 5	AL	EB		C	
0CW4A17306000	8- 6	AH	DX		C	
0CW4A17307000	8- 7	AF	DS		C	
0CW4A17308000	8- 18	AS	EZ		C	
0CW4A17309000	14- 62	AE	DJ		C	
0CW4A17310000	14- 63	AE	DJ		C	
0CW4A17311000	14- 65	AE	DJ		C	
0CW4A17312000	14- 66	AE	DJ		C	
0CW4A17314000	10- 36	AH	DX		D	
0CW4A17317000	2- 21	AC	DJ		C	
0CW4A17318000	3- 31	AK	DX		C	
0CW4A17319000	10- 40	AL	EB		C	
0CW4A17321000	3- 44	AR	EQ		C	
0CW4A17322000	13- 59	AD	DJ		C	
0CW4A17325000	9- 10	AE	DS		C	
0CW4A17327000	9- 18	AD	DJ		C	
0CW4A17328000	10- 5	AD	DJ		C	
0CW4A17329000	10- 24	AE	DS		C	
0CW4A17330000	11- 16	AD	DJ		C	
0CW4A17331000	11- 17	AD	DJ		C	
0CW4A17332000	11- 18	AC	DJ		C	
0CW4A17333000	11- 43	AN	EG		C	
0CW4A17335000	13- 7	AN	EG		C	
0CW4A17337000	11- 3	AE	DS		C	
0CW4A17338000	8- 8	AH	DX		C	
0CW4A17339000	11- 25	AC	DJ		C	
〃	13- 8	AC	DJ		C	
0CW4A17340000	14- 9	AG	DX		C	
0CW4A17341000	11- 52	AH	DX		C	
0CW4A17344000	11- 51	AE	DJ		C	
0CW4A17345000	11- 47	AE	DJ		C	
0CW4A17346000	11- 19	AC	DJ		C	
0CW4A17347000	11- 20	AD	DJ		C	
0CW4A17348000	11- 21	AD	DJ		C	
0CW4A17349000	4- 11	AF	DS		C	
0CW4A17350000	13- 10	AC	DJ		C	
0CW4A17351000	11- 22	AD	DJ		C	
0CW4A17352000	11- 39	AC	DJ		C	
0CW4A17353010	3- 6	AE	DJ		C	
0CW4A17354000	3- 7	AE	DJ		C	
0CW4A17355000	3- 37	AD	DJ		C	
0CW4A17357000	12- 11	AD	DJ		C	
0CW4A17358000	14- 12	AP	EQ		C	
0CW4A17359000	14- 13	AK	DX		C	
0CW4A17360000	14- 14	AK	DX		C	
0CW4A17361000	13- 15	AD	DJ		C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CW4A17362000	14- 16	AL	EB		C	
0CW4A17363000	12- 17	AH	DX		C	
0CW4A17364000	12- 18	AL	EB		C	
0CW4A17365000	14- 19	AF	DS		C	
0CW4A17366000	11- 23	AE	DJ		C	
0CW4A17367000	9- 11	AD	DJ		C	
0CW4A17368000	10- 17	AP	EQ		C	
0CW4A17371000	3- 8	AC	DJ		C	
〃	4- 14	AC	DJ		C	
〃	9- 5	AC	DJ		C	
0CW4A17372000	11- 26	AH	DX		C	
0CW4A17376000	12- 20	AF	DS		C	
0CW4A17377000	12- 21	AD	DJ		C	
0CW4A17378000	2- 15	AD	DJ		C	
0CW4A17379000	11- 48	AS	EQ		C	
0CW4A17380000	2- 58	AD	DJ		C	
0CW4A17381000	10- 18	AS	EQ		C	
0CW4A17383000	10- 6	AY	FQ		B	
0CW4A17384000	11- 71	AN	EG		C	
0CW4A17385000	12- 22	BN	HZ		C	
0CW4A17386000	14- 23	AE	DS		C	
0CW4A17387000	13- 24	AD	DJ		C	
0CW4A17388000	12- 25	AE	DS		C	
0CW4A17389000	14- 26	AG	DX		C	
0CW4A17390000	10- 1	AD	DJ		C	
0CW4A17391000	10- 39	AC	DJ		C	
0CW4A17392000	10- 7	AE	DS		C	
0CW4A17400000	2- 35	AC	DJ		C	
〃	3- 45	AC	DJ		C	
0CW4A17401000	11- 5	AD	DJ		C	
0CW4A17402000	10- 25	AC	DJ		C	
0CW4A17403000	14- 27	AE	DS		C	
0CW4A17404000	14- 28	AV	FG		C	
0CW4A17406000	11- 34	AH	DX		C	
0CW4A17407000	8- 21	AD	DJ		C	
0CW4A17408000	2- 36	AD	DJ		C	
0CW4A17409000	4- 34	AD	DJ		C	
0CW4A17414000	3- 10	AD	DJ		C	
0CW4A17415000	2- 14	AG	DS		C	
0CW4A17416000	9- 3	AD	DJ		C	
0CW4A17417000	3- 11	AD	DJ		C	
0CW4A17418000	4- 12	AD	DJ		C	
0CW4A17419000	3- 12	AD	DJ		C	
0CW4A17421000	9- 12	AE	DJ		C	
0CW4A17422000	9- 13	AE	DS		C	
0CW4A17423000	9- 14	AE	DS		C	
0CW4A17424000	2- 29	AF	DS		C	
0CW4A17425000	4- 48	AE	DS		C	
0CW4A17426000	4- 47	AH	DX		C	
0CW4A17427000	11- 32	AT	EZ		C	
0CW4A17467000	4- 40	AF	DS		C	
0CW4A17469000	7- 14	AD	DJ		C	
0CW4A17470000	14- 71	AP	EQ		C	
0CW4A17474000	3- 64	AG	DS		C	
0CW4A17475000	3- 66	AH	DX		C	
0CW4A17476000	12- 50	AC	DJ		C	
0CW4A17477000	12- 77	AN	EQ		C	
0CW4A17479000	8- 24	AD	DJ		C	
0CW4A17480000	13- 57	AP	EQ		C	
0CW4A17481000	13- 60	AE	DS		C	
0CW4A17482000	3- 54	AP	EQ		C	
0CW4A17483000	10- 61	AL	EB		C	
0CW4A17485000	12- 75	AK	DX		C	
0CW4A17486000	10- 51	AM	EG		C	
0CW4A17487000	10- 55	AF	DS		C	
0CW4A17488000	4- 28	AV	FG		D	
0CW4A17489000	3- 63	AG	DS		C	
0CW4A17491000	3- 55	AW	FG		C	
0CW4A17492000	14- 76	AF	DS		C	
0CW4A17495000	4- 25	AD	DJ		C	
0CW4A17496000	4- 26	AD	DJ		C	
0CW4A17504000	12- 74	AF	DS		C	
0CW4A17505000	4- 19	AD	DJ		C	
0CW4A17506000	4- 20	AE	DS		C	
0CW4A17507000	4- 21	AD	DJ		C	
0CW4A17508000	4- 22	AG	DX		C	
0CW4A17510000	3- 58	AK	DX		C	
0CW4A17511000	3- 56	AR	EQ		C	
0CW4A17512000	3- 61	AE	DJ		C	
0CW4A17513000	11- 41	AD	DJ		C	
0CW4A17514000	10- 33	AE	DS		C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CW4A17515000	4- 9	AC	DJ		C	
0CW4A17516000	8- 25	AK	DX		C	
0CW4A17517000	3- 14	AE	DS		C	
0CW4A17519000	10- 16	AR	EQ		D	
0CW4A17523000	3- 17	AC	DJ		C	
0CW4A17524000	3- 18	AD	DJ		C	
0CW4A17525000	12- 72	AD	DJ		C	
0CW4A17526000	9- 15	AF	DS		C	
0CW4A17528000	3- 19	AC	DJ		C	
0CW4A17530000	14- 29	AD	DJ		C	
0CW4A17531000	11- 37	AK	DX		C	
0CW4A17533000	12- 30	AC	DJ		C	
〃	13- 30	AC	DJ		C	
0CW4A17536000	14- 51	AC	DJ		C	
0CW4A17539000	3- 32	AK	DX		C	
0CW4A17540000	3- 33	AC	DJ		C	
0CW4A17542000	3- 20	AC	DJ		C	
0CW4A17543000	3- 62	AE	DS		C	
0CW4A17544000	14- 52	AR	EQ		C	
0CW4A17545000	14- 53	AQ	EQ		C	
0CW4A17549000	3- 34	AC	DJ		C	
0CW4A17551000	13- 31	AD	DJ		C	
0CW4A17552000	12- 32	AF	DS		C	
0CW4A17566000	12- 33	AD	DJ		C	
〃	13- 33	AD	DJ		C	
〃	8- 9	AD	DJ		C	
0CW4A17567000	10- 19	AD	DJ		C	
〃	13- 34	AD	DJ		C	
〃	14- 34	AD	DJ		C	
〃	3- 21	AD	DJ		C	
〃	8- 10	AD	DJ		C	
0CW4A17572000	10- 20	AE	DJ		C	
〃	3- 22	AE	DJ		C	
〃	8- 11	AE	DJ		C	
0CW4A17573000	12- 36	AE	DS		C	
〃	13- 36	AE	DS		C	
〃	8- 12	AE	DS		C	
0CW4A17575010	10- 43	AE	DS		D	
0CW4A17576000	3- 53	AH	DX		C	
0CW4A17577000	3- 2	AE	DS		C	
0CW4A17578000	3- 49	AD	DJ		C	
0CW4A17581000	15- 28	AF	DS		C	
0CW4A17583000	15- 31	AD	DJ		C	
0CW4A17584000	15- 29	AD	DJ		C	
0CW4A17585000	11- 42	AE	DJ		C	
0CW4A17589000	16- 9	AD	DJ		C	
0CW4A17590000	15- 51	AC	DJ		C	
0CW4A17591000	16- 8	AF	DS		C	
0CW4A17592000	15- 10	AE	DJ		C	
0CW4A17691000	3- 23	AC	DJ		C	
0CW4A18198000	15- 36	AC	DJ		C	
0CW4A18206000	15- 1	AD	DJ		C	
0CW4A18207000	15- 2	AN	EQ		C	
0CW4A18210000	15- 35	AD	DJ		C	
0CW4A18211000	15- 56	AD	DJ		C	
0CW4A18214000	15- 3	AG	DX		D	
0CW4A18215000	16- 4	AF	DS		C	
0CW4A18217000	15- 5	AE	DS		C	
0CW4A18218000	16- 6	AF	DS		C	
0CW4A18219000	16- 7	AF	DS		C	
0CW4A18225000	15- 11	AD	DJ		C	
0CW4A18226000	16- 12	AE	DJ		C	
0CW4A18227000	15- 57	AP	EQ		B	
0CW4A18229000	16- 14	AF	DS		C	
0CW4A18230000	16- 15	AE	DJ		C	
0CW4A18232000	15- 48	AF	DS		C	
0CW4A18238000	15- 22	AR	EQ		D	
0CW4A18240000	15- 26	AQ	EQ		C	
0CW4A18263000	16- 30	AE	DS		D	
0CW4A18264000	16- 25	AE	DS		D	
0CW4A18265000	16- 24	AE	DS		D	
0CW4A18313000	2- 24	AE	DJ		C	
0CW4A18314000	4- 29	AC	DJ		C	
0CW4A18316000	4- 8	AD	DJ		D	
0CW4A18319000	10- 21	AD	DJ		C	
0CW4A18320000	11- 61	AC	DJ		C	
0CW4A18322000	14- 70	AC	DJ		C	
0CW4A18323000	12- 80	AC	DJ		C	
0CW4A18324000	13- 58	AE	DS		C	
0CW4A18325000	13- 79	AN	EG		C	
0CW4A18326000	13- 56	AK	DX		C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CW4A18327000	13- 55	AL	EB		C	
0CW4A18328000	13- 83	AC	DJ		C	
0CW4A18329000	13- 37	AC	DJ		C	
0CW4A18330000	12- 38	AD	DJ		C	
0CW4A18331000	13- 39	AD	DJ		C	
0CW4A18332000	12- 40	AR	EQ		C	
0CW4A18334000	10- 22	AC	DJ		C	
0CW4A18338010	2- 39	AH	DX		C	
0CW4A18672000	5- 9	AY	FQ		C	
0CW4A18673000	5- 10	AF	DS		D	
0CW4A18679000	5- 13	AF	DS		C	
0CW4A18680000	5- 14	AF	DS		C	
0CW4A18681000	5- 15	AM	EG		C	
0CW4A18682000	6- 5	AG	DX		D	
0CW4A18683000	5- 5	AE	DJ		C	
0CW4A18684000	5- 55	AF	DS		C	
0CW4A18685000	5- 2	AF	DS		C	
0CW4A18686000	5- 17	AT	EZ		D	
0CW4A18688000	6- 1	AD	DJ		C	
0CW4A18689000	5- 56	AF	DS		C	
0CW4A18690000	6- 21	AH	DX		C	
0CW4A18704000	5- 21	AN	EQ		D	
0CW4A18708000	5- 22	AY	FQ		C	
0CW4A18857000	2- 1	AG	DX		C	
0CW4A18863000	4- 44	AE	DJ		C	
0CW4A18869000	4- 43	AE	DS		C	
0CW4A18877000	10- 37	AF	DS		D	
0CW4A18881000	15- 55	AF	DS		C	
0CW4A18884000	16- 34	BF	GN		E	
0CW4A18888000	11- 69	AN	EG		C	
0CW4A18889010	10- 13	AD	DJ		C	
0CW4A18904000	15- 13	AF	DS		C	
0CW4A18905000	15- 17	AH	DX		C	
0CW4A18907000	15- 23	AH	DX		D	
0CW4A18910000	1- 34	AH	DX		C	
0CW4A18919000	1- 6	AN	EG		C	
0CW4A18920000	1- 11	AH	DX		C	
0CW4A18921000	1- 25	AH	DX		C	
0CW4A18923000	1- 37	AM	EG		C	
0CW4A18924010	10- 28	AD	DJ		C	
0CW4A18926000	1- 26	AK	EB		C	
0CW4A18927000	1- 27	AK	EB		C	
0CW4A18928000	1- 1	BD	GN		C	
0CW4A18934000	1- 30	AR	EQ		C	
0CW4A18935000	1- 43	AF	DS		C	
0CW4A18936000	1- 31	AX	FG		C	
0CW4A18937000	1- 33	AN	EQ		C	
0CW4A18938000	1- 32	AH	DX		C	
0CW4A18939000	1- 35	AF	DS		C	
0CW4A18948000	4- 42	AN	EG		C	
0CW4A18951000	4- 41	AG	DX		C	
0CW4B10082000	10- 68	AF	DS		C	
0CW4B10085000	10- 65	AK	EB		C	
0CW4B10086000	10- 63	AL	EB		C	
0CW4B10087000	10- 67	AK	EB		C	
0CW4B10111000	11- 68	AE	DS		C	
0CW4B10138010	10- 23	AU	EZ		C	
0CW4B10140000	11- 65	AN	EQ		C	
0CW4B10144000	10- 64	AE	DJ		C	
0CW4B10149000	11- 66	AD	DJ		C	
0CW4B10156000	10- 66	AE	DJ		C	
0CW4B10389000	1- 9	AU	EZ		C	
0CW4B10390000	3- 51	AN	EQ		C	
0CW4B10391000	1- 20	AD	DJ		C	
0CW4B10394000	2- 53	AL	EB		C	
0CW4B10395000	2- 52	AL	EB		C	
0CW4B10476000	6- 10	AG	DS		D	
0CW4B10477000	6- 12	AG	DS		C	
0CW4B10485000	18- 12	AF	DS		D	
0CW4B10486000	18- 13	AF	DS		D	
0CW4B10488000	18- 11	AF	DS		D	
0CW4B10489000	18- 10	AF	DS		D	
〃	5- 8	AF	DS		D	
0CW4B10490000	6- 20	AG	DX		C	
0CW4B10493000	5- 25	AE	DS		C	
0CW4B10494000	5- 53	AS	EQ		C	
0CW4B10495000	5- 18	AQ	EQ		D	
0CW4B10584000	2- 43	AD	DJ		C	
0CW4B10585000	2- 25	AD	DJ		C	
0CW4B10586010	4- 4	AC	DJ		C	
0CW4B10591000	11- 56	AF	DS		C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CW4B10740000	15- 53	AE	DS		C	
0CW4B10742000	15- 50	AF	DS		C	
0CW4B10743000	15- 27	AE	DJ		C	
0CW4B10744000	15- 44	AE	DJ		C	
0CW4B10746000	15- 47	AD	DJ		C	
0CW4B10754000	15- 43	AE	DJ		C	
0CW4B10776000	10- 49	AF	DS		C	
0CW4B10778000	10- 46	AF	DS		C	
0CW4B10779000	10- 45	AF	DS		C	
0CW4B10780000	2- 13	AF	DS		C	
0CW4B10783000	9- 19	AG	DX		C	
0CW4B10785000	3- 50	AC	DJ		C	
0CW4B10845000	2- 51	AD	DJ		C	
0CW4B10846000	11- 53	AD	DJ		C	
0CW4B10847000	5- 23	AF	DS		D	
0CW4B10848000	2-504	AB	DJ		C	
0CW4B10851000	2- 50	AD	DX		C	
0CW4B10852000	10- 57	AE	DS		C	
0CW4F11556000	3- 27	AG	DX		C	
0CW4F11557000	4- 15	AH	DX		C	
0CW4F11558000	3- 65	AH	DX		C	
0CW4F11560000	3- 60	AH	DX		C	
0CW4F11562000	7- 15	AT	EZ		C	
0CW4F11563010	8- 27	BA	FX		C	
0CW4F11564000	10- 53	AW	FG		C	
0CW4F11565000	11- 59	AP	EQ		C	
0CW4F11566000	9- 22	AG	DX		C	
0CW4F11568010	12- 78	AY	FQ		C	
0CW4F11569000	13- 75	AK	DX		C	
0CW4F11570000	13- 76	AK	DX		C	
0CW4F11679000	15- 32	AF	DS		C	
0CW4F11850000	5- 52	AU	EZ		C	
0CW4F11882000	3- 47	AT	EZ		C	
0CW4F11883000	3- 52	AN	EQ		C	
0CW4F12053000	15- 46	AH	DX		C	
0CW4G11297020	5- 1	CA	TR		E	
0CW4H16449010	10- 44	AM	EG		B	
〃	4- 17	AM	EG		B	
0CW4H16450000	14- 45	AT	EZ		E	
0CW4H16452000	4- 30	AQ	EQ		C	
0CW4H16453000	4- 31	AU	EZ		C	
0CW4H16454000	10- 2	AE	DS		C	
〃	4- 13	AE	DS		C	
〃	9- 1	AE	DS		C	
0CW4H16455000	10- 10	AK	EB		C	
0CW4H16456000	14- 41	AN	EG		C	
0CW4H16458000	7- 5	AK	DX		C	
0CW4H16460000	3- 41	AP	EQ		C	
0CW4H16461000	4- 32	AN	EQ		C	
0CW4H16462000	4- 33	AL	EB		C	
0CW4H16464000	10- 26	AN	EQ		C	
0CW4H16465000	4- 35	AQ	EQ		C	
0CW4H16467000	3- 43	AP	EQ		C	
0CW4H16468000	8- 22	AY	FQ		C	
0CW4H16504000	16- 39	AK	DX		C	
0CW4H16505000	16- 40	AH	DX		C	
0CW4H16506000	15- 41	AW	FG		C	
0CW4H16512000	3- 16	AF	DS		C	
0CW4H16514000	5- 3	AP	EQ		C	
0CW4H16515000	5- 4	AH	DX		C	
0CW4H16523000	6- 2	BA	FX		C	
0CW4H16524000	5- 6	AV	FG		C	
0CW4H16530000	5- 20	AG	DX		C	
0CW4H16531000	6- 15	AP	EQ		C	
0CW4H16553000	4- 36	AS	EQ		C	
0CW4H16602000	3- 42	AU	EZ		C	
0CW4K11066000	10- 34	BE	GN		B	
0CW4K11067000	10- 11	BA	FX		B	
0CW4K11069000	8- 19	BR	LX		B	
0CW4K11070000	15- 42	BE	GN		B	
0CW4K11078000	5- 19	BB	FX		B	
0CW4K11080000	3- 35	BF	GN		B	
0CW4K14040000	12- 42	BB	GD		B	
0CW4S10280000	15- 45	AD	DS		C	
0CW4S12048000	2- 18	AL	EB		C	
0CW4S12049000	2- 19	AL	EB		C	
0CW4S19048000	13- 43	AC	DJ		C	
0CW4S19049000	8- 23	AD	DJ		C	
0CW4S19076000	15- 21	AC	DJ		C	
0CW4S19077000	3- 26	AC	DJ		C	
〃	4- 2	AC	DJ		C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CW61637/////	17- 16	AA	DJ	N	D	
0CW616371////	18- 8	AA	DJ		D	
〃	25- 9	AA	DJ		D	
0CWCLP00010//	1- 55	AD	DJ	N	C	
0CWE312001475	19- 2	AF	DS		B	
0CWE314000784	23- 15	AP	EQ	N	B	
〃	24- 32	AP	EQ	N	B	
0CWE321000945	19- 3	AT	EZ	N	B	
0CWE323000483	19- 5	AH	DX	N	B	
0CWE323000494	19- 4	AH	DX	N	B	
0CWE450000384	22- 15	AB	DD		C	
〃	24- 53	AB	DD		C	
0CWE450001128	23- 40	AC	DJ		C	
〃	24- 44	AC	DJ		C	
0CWE450001139	24- 35	AC	DJ		C	
0CWE450001148	23- 39	AE	DS	N	C	
0CWE450001297	24- 45	AH	DX	N	C	
0CWE73543M476	19- 6	AD	DJ		C	
0CWE74561WE03	24- 54	AE	DS	N	C	
0CWE74566WE03	19- 7	AD	DJ	N	C	
0CWE74566WE04	19- 8	AD	DJ	N	C	
0CWE75317BK22	24- 38	BB	GD	N	C	
0CWE7709532//	19- 9	AF	DS	N	B	
0CWER040SKP//	21- 13	AB	DD		C	
〃	22- 8	AB	DD		C	
〃	23- 13	AB	DD		C	
0CWER050SKP//	23- 20	AA	DD		C	
〃	24- 29	AA	DD		C	
0CWER060SKN//	2- 66	AA	DJ	N	C	
0CWFB55968000	6- 11	AH	DX		C	
0CWFB55969000	6- 22	AE	DJ		C	
0CWFB56775000	6- 9	AH	DX		C	
0CWFC15034000	15- 19	AC	DJ		C	
0CWFC21175000	14- 35	AC	DJ		C	
0CWFC22120000	10- 3	AC	DJ		C	
〃	11- 8	AC	DJ		C	
〃	12- 44	AC	DJ		C	
〃	13- 44	AC	DJ		C	
〃	1- 39	AC	DJ		C	
〃	14- 44	AC	DJ		C	
〃	2- 28	AC	DJ		C	
〃	3- 4	AC	DJ		C	
〃	4- 3	AC	DJ		C	
〃	5- 7	AC	DJ		C	
〃	7- 7	AC	DJ		C	
〃	8- 13	AC	DJ		C	
〃	9- 2	AC	DJ		C	
0CWFC25031000	8- 17	AC	DJ		C	
0CWFC25034000	10- 12	AB	DJ		C	
〃	3- 36	AB	DJ		C	
〃	7- 8	AB	DJ		C	
0CWFC25035000	16- 20	AC	DJ		C	
0CWFC25827000	10- 29	AE	DJ		C	
〃	11- 9	AE	DJ		C	
〃	12- 46	AE	DJ		C	
〃	13- 46	AE	DJ		C	
〃	14- 46	AE	DJ		C	
〃	2- 6	AE	DJ		C	
〃	3- 28	AE	DJ		C	
〃	4- 5	AE	DJ		C	
〃	7- 9	AE	DJ		C	
〃	9- 6	AE	DJ		C	
0CWFC30661000	1- 36	AC	DJ		C	
〃	15- 18	AC	DJ		C	
0CWFC30779000	1- 41	AC	DJ		C	
〃	15- 33	AC	DJ		C	
0CWFF60507000	6- 7	AV	FG		C	
0CWFF60508000	6- 8	AV	FG		C	
0CWFS19009000	3- 5	AC	DJ		C	
0CWFS19102000	6- 3	AC	DJ		C	
0CWFS21615000	14- 47	AS	EZ		C	
〃	8- 14	AS	EZ		C	
0CWFS21672000	10- 30	AD	DJ		C	
〃	11- 27	AD	DJ		C	
〃	12- 48	AD	DJ		C	
〃	14- 48	AD	DJ		C	
〃	4- 6	AD	DJ		C	
〃	7- 10	AD	DJ		C	
0CWFS26593000	1- 29	AD	DJ		C	
0CWFS56528000	6- 4	AE	DJ		C	
0CWHW030FNS//	21- 16	AC	DJ	N	C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CWHW030FNS//	22- 26	AC	DJ	N	C	
0CWHW050FZS00	13- 82	AB	DJ		C	
0CWHW080FWS//	1- 54	AC	DJ	N	C	
0CWNSBLT00333	23- 25	AS	EQ	N	B	
0CWNSBLT00338	23- 19	AS	EQ	N	B	
0CWNSBLT00339	23- 23	AR	EQ	N	B	
0CWNSBRG00110	22- 7	AU	EZ	N	C	
〃	23- 12	AU	EZ	N	C	
0CWNSBSH00002	21- 11	AH	DX	N	C	
〃	24- 13	AH	DX	N	C	
0CWNSCLP00005	20- 10	AE	DJ	N	C	
〃	22- 24	AE	DJ	N	C	
〃	24- 12	AE	DJ	N	C	
0CWNSCLP00008	20- 8	AE	DJ	N	C	
〃	24- 11	AE	DJ	N	C	
0CWNSSCR00017	22- 12	AD	DJ	N	C	
〃	23- 16	AD	DJ	N	C	
〃	24- 21	AD	DJ	N	C	
0CWNSSCR00087	23- 8	AE	DS	N	C	
0CWNSSCR00225	24- 36	AC	DJ	N	C	
0CWNSSCR00226	22- 2	AE	DJ	N	C	
0CWPW060025//	23- 37	AA	DJ		C	
0CWPW060050//	12- 82	AA	DD		C	
0CWRA22452000	15- 52	AC	DJ		C	
0CWSCR00045//	17- 22	AC	DJ		C	
0CWVT20002018	4- 50	AE	DJ		C	
0CWVT25019030	4- 49	AE	DS		C	
0CWVT25171030	4- 51	AE	DS		C	
0CWWA70484000	5- 51	AN	EG		B	
0CWWG85362000	10- 14	AH	DX		B	
〃	11- 28	AH	DX		B	
〃	12- 54	AH	DX		B	
〃	3- 25	AH	DX		B	
〃	4- 7	AH	DX		B	
〃	5- 16	AH	DX		B	
〃	6- 6	AH	DX		B	
〃	7- 11	AH	DX		B	
〃	9- 16	AH	DX		B	
0CWWG85421000	8- 20	AR	EQ		B	
0CWWT25035000	23- 36	AD	DJ		C	
0CWXB12300605	15-502	AB	DJ		C	
〃	6-501	AB	DJ		C	
0CWXB12300805	6-507	AB	DJ		C	
0CWXB12400605	5-501	AB	DJ		C	
0CWXB12400606	10-504	AB	DJ		C	
0CWXB12400607	15-505	AB	DJ		C	
0CWXB12400805	6-508	AB	DJ		C	
0CWXB12401005	13-501	AB	DJ		C	
0CWXB24300605	5-504	AB	DJ		C	
0CWXB24300805	6-505	AB	DJ		C	
0CWXB47300607	2-503	AB	DJ		C	
0CWXB47300805	5-502	AB	DJ		C	
〃	6-502	AB	DJ		C	
0CWXB47301209	6-504	AB	DJ		C	
0CWXB47401006	2- 81	AB	DJ		C	
0CWXB47401007	10-501	AB	DJ		C	
〃	11-502	AB	DJ		C	
〃	15-503	AB	DJ		C	
〃	2-502	AB	DJ		C	
〃	3-502	AB	DJ		C	
〃	4-501	AB	DJ		C	
0CWXD11104629	5-503	AC	DJ		C	
0CWXD12300142	3-503	AC	DJ		C	
0CWXD21100402	13- 81	AC	DJ		C	
0CWXD21100502	12- 83	AC	DJ		C	
〃	15-501	AC	DJ		C	
〃	16-501	AC	DJ		C	
〃	6-503	AC	DJ		C	
0CWXD21100642	15-504	AC	DJ		C	
〃	16-504	AC	DJ		C	
〃	6-506	AC	DJ		C	
0CWXD32200102	10-503	AC	DJ		C	
〃	11-501	AC	DJ		C	
〃	12-502	AC	DJ		C	
〃	14-502	AC	DJ		C	
0CWXD32200122	10-502	AC	DJ		C	
〃	4-502	AC	DJ		C	
〃	7-501	AC	DJ		C	
〃	8-503	AC	DJ		C	
0CWXD32200142	13-503	AC	DJ		C	
〃	16-508	AC	DJ		C	

PARTS CODE	NO.	PRICE R.		NEW	P/R	
		Ex.	Ja.			
0CWXD32200142	3-501	AC	DJ		C	
〃	7-502	AC	DJ		C	
〃	8-501	AC	DJ		C	
0CWXD32300122	16-506	AC	DJ		C	
0CWXD32300142	14-504	AD	DJ		C	
〃	15-507	AD	DJ		C	
0CWXD32300162	12-505	AC	DJ		C	
0CWXD32300182	14-506	AC	DJ		C	
〃	8-502	AC	DJ		C	
0CWXF21309000	16- 16	AS	EZ		B	
〃	16- 42	AS	EZ		B	
0CWXF21604940	11- 29	AL	EB		B	
0CWXF21605040	3- 46	AL	EB		B	
0CWXF21606140	10- 4	AL	EB		B	
0CWXF21607240	14- 49	AN	EG		B	
0CWXF21607440	4- 18	AK	DX		B	
0CWXF21607640	11- 30	AN	EG		B	
0CWXF21608040	7- 12	AN	EG		B	
0CWXF21618840	3- 40	AP	EQ		B	
0CWXF21619860	3- 39	AQ	EQ		B	
0CWXF21804070	15- 49	AQ	EQ		B	
0CWXF21807000	8- 15	AP	EQ		B	
0CWXF21817960	3- 38	AS	EZ		B	